



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		853280	INJECTOR	8		
2		NSS	CLAMP-Injector	8		12
3	10	853281	SCREW-Injector Hold Down	8		
3	10	853282	SCREW-Injector Hold Down (Shoul	8		
4	10	853278	SCREW (M6 x 35)	8		
5		853279	SPOUT	8		
6		853428A 1	SEAL SET-Injector	8		
7	25	853283	RING-Injector Back-up	8		
8	25	853284	RING-Injector Upper Cushion	8		
9	26	853285	SEAL-Injector Upper	8		
10	26	853286	SEAL-Injector Middle	8		
11	25	853284	RING-Injector Middle Cushion	8		
12	26	853288	SEAL-Injector Lower	8		
13	27	853289	GASKET-Injector	8		
14	22	853290	CONNECTOR (90 Deg.)	1		
15	54	853368	CLAMP	2		
16	25	853134	O-RING	4		
17	22	853295	ELBOW (90 Deg.)	1		
18	32	853296	CONDUIT	1		
19	22	853297	ELBOW (45 Deg.)	2		
20	32	853298	HOSE-High Pressure Oil	1		
21	22	853150	CONNECTOR	1		
22		853205	TAPPET	1		
23		853102	REGULATOR-Injection Oil Control	1		
24		NSS	CONNECTOR	1		12
25		NSS	ELBOW	1		12
26		853142	PUMP	1		
27	10	853255	SCREW (50mm)	1		
27	10	853247	SCREW (70mm)	1		
28	27	853267	GASKET	1		
29		853361	PUMP	1		
30	10	853227	SCREW (M8 x 30)	2		
31	27	853362	GASKET	2		
32	10	853363	SCREW	1		
33	32	853364	TUBE-Fuel Supply	1		
34	32	853365	HOSE-High Pressure Oil	1		
35	32	853366	HOSE-To Fuel Pressure Regulator	1		
36	22	853367	CONNECTOR	1		
37	32	853430	HOSE-To Fuel Pressure Regulator	1		