



4298

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	429	879834A 1	CRANKSHAFT ASSEMBLY	1	(INCLUDES CONNECTING ROD)	
2	23	853067	BEARING, Main (Standard)	4		
2	23	853068	BEARING, Main (.010)	AR		
2	23	853069	BEARING, Main (.020)	AR		
2	23	853070T	BEARING, Main (.030)	AR		
3	23	853071	BEARING, Rear Main (Standard)	1		
3	23	853072	BEARING, Rear Main (.010)	AR		
3	23	853073	BEARING, Rear Main (.020)	AR		
3	23	853074	BEARING, Rear Main (.030)	AR		
4	43	853065	GEAR, Crankshaft	1		
5	28	853066	KEY, Crankshaft	2		
6	17	853081	PIN, (.375 x 1.00 Inch)	1		
7	10	853061	BOLT, (M16 x 60)	1		
8	12	853062	WASHER, Crankshaft	1		
9		853063	DAMPER ASSEMBLY	1		
10	23	853064	SLEEVE, Front Oil Seal/Wear	1		
11	222	862753A 1	FLYWHEEL ASSEMBLY	1		
12	43	853075	GEAR, Flywheel Ring	1		
13		853079	RING, Reinforcement	1		
14	10	853080	BOLT	10		
15		853274T	COUPLER PLATE	1		
16	10	802773	SCREW, (.3125-18 x 1.25)	6		
17	12	40023 17	WASHER	6		
18		805684A 2	COUPLING	1		
19	10	47461	SCREW, (.437-14 x 1.00)	6		
19	10	40001192	SCREW, (M10 x 25)	6		