



4352

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		853280T	INJECTOR	8		
2		NSS	NOT SOLD SEPARATE, Injector	8		
3	10	853281	SCREW, Injector Hold Down	8		
3	10	853282	SCREW, Injector Hold Down (Sho	8		
4	10	853278	SCREW, (M6 x 35)	8		
5		853279	SPOUT	8		
6		853428A 1	SEAL SET, Injector	8		
7	25	853283	RING, Injector Back-Up	8		
8	25	853284	RING, Injector Upper Cushion	8		
9	26	853285	SEAL, Injector Upper	8		
10	26	853286	SEAL, Injector Middle	8		
11	25	853284	RING, Injector Middle Cushion	8		
12	26	853288	SEAL, Injector Lower	8		
13	27	853289	GASKET, Injector	8		
14	22	853290	CONNECTOR, (90 Degree)	1		
15	54	853368	CLAMP	2		
16	25	853134	O-RING	4		
17	22	853295	FITTING, Elbow (90 Degree)	1		
18	32	802774	CONDUIT	1		
19	22	853297	FITTING, Elbow (45 Degree)	2		
20	32	864334	HOSE ASSEMBLY, High Pressure I	1		
21	22	853150	CONNECTOR	1		
22		853205	TAPPET	1		
23		853102A02	REGULATOR, Injection Oil Control	1		
24		NSS	NOT SOLD SEPARATE, Connec	1		
25		NSS	NOT SOLD SEPARATE, Elbow	1		
26		853142	PUMP	1		
27	10	853255	SCREW, (50mm)	1		
27	10	853247	SCREW, (70mm)	1		
28	27	853267	GASKET	1		
29		853361	PUMP	1		
30	10	853227	SCREW, (M8 x 30)	2		
31	27	853362	GASKET	2		
32	10	853363	SCREW	1		
33	32	853364	TUBE, Fuel Supply	1		
34	32	864334	HOSE ASSEMBLY, High Pressure I	1		
35	32	853366	HOSE, To Fuel Pressure Regulator	1		
36	22	864335	FITTING	1		
37	32	853430	HOSE, To Fuel Pressure Regulator	1		