



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		830401261	ALTERNATOR ASSEMBLY-With F	1		
-		830401262	ALTERNATOR ASSEMBLY-With F	1		
1		831016080	NUT-Lock	1		
2		839016480	LOCKWASHER	1		
3		834311380	PULLEY-Alternator	1		
4		834411170	FAN-Alternator	1		
5		833171440	BOLT-Through	3		
6		833101510	FRAME ASSEMBLY-Alternator Di	1		
7		833621090	BOLT-Through	3		
8		833121520	PLATE-Retainer	1		
9		834121140	COLLAR-Space	1		
10	30	838120122	BEARING-Ball	1	(FOR ALTERNATOR ASSY 8304	
10		832521630	BEARING-Ball	1	(FOR ALTERNATOR ASSY 8304	
11		834121150	COLLAR-Space	1		
12		834101600	STATOR ASSEMBLY	1		
13		833301530	ROTOR ASSEMBLY-Alternator	1		
14		833331030	RING-Space	1		
15		838112102	BEARING-Ball	1		
16		833561220	HOLDER-With Rectifier	1		
17		833711170	BRUSH-Alternator	2		
18		833761030	HOLDER-Brush B	2		
19		833871170	INSULATOR-Terminal B	1		
20		837001520	REGULATOR ASSEMBLY	1		
21		833641450	BOLT-Terminal	1		
22		833651080	WIRE-Lead	1		
23		833781600	INSULATOR-Terminal	1		
24		833871160	INSULATOR-Terminal B	2		
25		830105040	NUT	4		
26	11	830106050	NUT	2		
27		833551180	CONDENSER-Alternator	1		
28		833871150	INSULATOR-Terminal B	1		
29		833591810	FRAME-Rectifier End	1		
30		833511020	BUSH-Frame	1		
31		834451190	CLAMP	1		