



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		830124277	BOLT	1	
2	12	835912111	WASHER	1	11
3	10	831110001	BOLT	1	
4	10	831110352	BOLT	1	
5	10	831910104	BOLT	1	
6		835910130	BOLT	1	
7		838012300	LOCKWASHER	1	
8		836012220	WASHER	1	
9	22	830235125	CONNECTOR PIPE	1	
10	25	835125103	O RING	2	
11		836911190	GASKET-Oil Filter	1	
12	25	834402135	O RING	3	
13		836002880	FILTER ASSEMBLY-Oil	1	(SEE FILTER ASSEMBLY - OIL)
14		835818181	PLATE-Caution	1	
15		830481160	BRACKET ASSEMBLY-Oil Pipe	1	
16	12	836010220	WASHER	4	
17	10	831110200	BOLT	1	
18		831041240	STRAINER ASSEMBLY-Oil	1	
19	10	839108162	BOLT	2	
20	25	834402135	O RING	1	
21		834111370	PIPE-Oil Pump Inlet	1	
22	10	838108250	BOLT	2	
23	25	835125103	O RING	1	
24		838010250	LOCKWASHER	3	
25		830010080	NUT	1	
26		838908110	BOLT	2	
27	25	834402135	O RING	1	
28	10	839108552	BOLT	2	
29	10	831110651	BOLT	2	
30		831101382	PUMP ASSEMBLY-Oil	1	(SEE PUMP ASSEMBLY - OIL)
31	10	831110401	BOLT	1	
32		832531050	GASKET-Oil Cooler Case	2	
33		837111210	CASE-Oil Cooler	1	
34	10	835908103	BOLT	2	
35	10	839108452	BOLT	7	
36	27	836925101	GASKET-Flange	1	
37	12	836008180	WASHER	2	
38	13	838008200	LOCKWASHER	2	
39	10	839008176	BOLT	2	
40		831341040	PIPE-Coolant Oil Cooler	1	
41		836404420	CLAMP	2	