



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		831002050	STARTER ASSEMBLY	1		16
-		831002051	STARTER ASSEMBLY	1		
-		831002052	STARTER ASSEMBLY	1		
41		831201490	YOKE ASSEMBLY-Start	1		
42		831122160	BOLT-Housing Set	4		
43		831211380	COIL-Start Field	1		
44		832631090	PIN-Weight	1		
45		831122170	BOLT-Housing Set	1		
46		832311120	NUT	1		
47		832191120	WASHER	1		
48		832191200	WASHER	1		
49		831251230	BUSH-Center Bearing	1		
50		835110126	O RING	1		
51		831251220	BUSH-Center Bearing	1		
52		832411090	WASHER-Contact Plate Lock	1		
53		831401340	HOLDER ASSEMBLY-Start Brush	1		
54		831421330	BRUSH-Start	4		
55		831121050	BOLT-Housing Set	4		
56	24	831431121	SPRING-Start Brush	4		
57		831331600	FRAME-Commutator End	1		
58		832631090	PIN-Weight	1		
59		832521400	BEARING	1		
60		835106118	O RING	4		
61		831381420	PACKING	1		
62		831122190	BOLT-Housing Set	2		
63		832311130	NUT	2		
64		831010060	NUT-Lock	1		