



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		831001980	TURBOCHARGER ASSEMBLY	1		
1		831111330	CASE-Turbine	1		
2		831231270	PLATE	1		
3		831451270	BOLT	6		
4		831501280	ROTOR ASSEMBLY	1		
5		831151240	ROTOR-Turbine	1		
6		831241170	SEAL-Ring	1		
7		831421070	SPACER-Thrust	1		
8		831431060	BEARING-Inboard Thrust	1		
9		831361120	SCREW	4		
10		831161040	THROWER-Oil	1		
11		831241180	SEAL-Ring	1		
12		831241190	SEAL-Ring	1		
13		831181160	IMPELLER-Blower	1		
14		831171140	NUT-Lock	1		
15		831411060	PROTECTOR-Heat	1		
16		831211140	CASE-Bearing	1		
17		831321080	RING-Nozzle	3		
18		831311110	BEARING	2		
19		831271120	PLATE-Back	1		
20		831361170	SCREW	4		
21		831451260	BOLT	6		
22		831231260	PLATE	6		
23		831141180	CASE-Blower	1		
24	27	831041090	GASKET	1		