



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		34285A	GIMBAL RING ASSEMBLY	1		
2	31	32538	BEARING, ROLLER - GIMBAL R	1		
3	26	32541	OIL SEAL, GIMBAL RING	2		
4	22	23612	FITTING, GREASE-GIMBAL RIN	1		
5		29359	LUBRICAP, GIMBAL RING GREA	1		
6	17	36179	PIN, HINGE - GIMBAL RING TO BI	2		
7	17	35571	PIN, HINGE PIN RETAINING - GIM	2		
8	55	35998	SHOCK ABSORBER	2		
9	23	32848	BUSHING, RUBBER - SHOCK ABS	4		
10	55	32607	PIN, SHOCK ABSORBER TO GIMB	2		
11	17	35571	PIN, SHOCK ABSORBER PIN RET	2		
12	17	35779A	PIN ASSEMBLY, SHOCK ABSORB	1		
13	12	35777	WASHER, SHOCK ABSORBER	2		
14	11	35778	NUT, SHOCK ABSORBER TO D	2		
15	17	35813A	TILT PIN ASSEMBLY, GIMBAL RIN	1	NOT USED WITH FULL POWER	
16	11	35814	NUT, TILT ADJUSTMENT PIN	2	NOT USED WITH FULL POWER	
17		32688A	TILT STOP SWITCH ASSEMBLY,	1		
18	10	20367	SCREW, TILT STOP SWITCH CO	2		
19	23	31902	SPACER, TILT STOP SWITCH TO	1		
20		31899	PLATE, RETAINING - TILT STOP SV	2		
21	10	22387	SCREW, RETAINING PLATE AND	2		
22		32637	STRAP, TILT STOP SWITCH RET	1		
23	11	20110	NUT, TILT STOP SWITCH RETAI	2		
24		31897	LEVER, TILT STOP SWITCH ACT	1		
25	10	31903	SCREW, TILT STOP SWITCH AC	2		
26		32630	LEVER, STEERING - UPPER SWI	1		
27		32582	SHAFT, UPPER SWIVEL - GIMBAL	1		
28	22	32561	PLUG, PIPE - UPPER SWIVEL SH	1		
29	12	32996	WASHER, UPPER SWIVEL SHAF	AR		
29	12	32997	WASHER, UPPER SWIVEL SHAF	AR		
30	10	32995	SCREW, STEERING LEVER TO U	1		
31	11	20696	NUT, STEERING LEVER TO UPPI	1		
32	10	33022	SCREW, UPPER SWIVEL SHAFT	1		
33	12	20546	WASHER, UPPER SWIVEL SHAF	1		
1	16	32568	STUD, PIVOT - STEERING LEVE	1		
35	12	25909	WASHER, STEERING LEVER PIV	3		
36	12	29330	WASHER, NYLON - STEERING LI	1		
37		29332A	ROD, STEERING LINK - STEERIN	1		
38		29698	BALL, STEEL - STEERING LEVER	1		
39	24	20510	SPRING, STEERING LEVER PIVO	1		
40	22	26915	BUSHING, STEERING LEVER PIV	1		