



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		48165A 5	REVERSE LOCK VALVE ASSEMB	1		
2		45709	FOLLOWER, CAM	1		
3	22	48166	ELBOW, HYDRAULIC TRIM HO:	1		
4	22	48167	CONNECTOR, ELBOW	1		
5	22	21290	PLUG, PIPE-REVERSE LOCK VA	1		
6	13	25906	WASHER, WAVE-REVERSE LO	1		
7	25	45710	"O" RING, REVERSE LOCK VAL	1		
8		45526	CAM, REVERSE LOCK VALVE	1		
9	10	46736	SCREW, CAM TO CAM LEVER (1		
10	13	26996	LOCKWASHER, CAM SCREW	1		
11		45528	COVER, REVERSE LOCK VALVE	1		
12	25	45711	"O" RING, VALVE COVER	1		
13	30	45712	BALL, VALVE COVER	30		
14	12	45713	WASHER, RETAINING-BALL TC	1		
15	10	45716	SCREW, COVER TO REVERSE	4		
16	11	20110	NUT, COVER SCREW	4		
17		46732A 1	LEVER ASSEMBLY, CAM	1		
18	16	45715	STUD, SHIFT CONTROL LEVE	2		
19		49413	LEVER, SHIFT CONTROL-CAM LE	1		
19		53759	LEVER, SHIFT CONTROL-CAM LE	1		
20	12	21273	WASHER, CAM LEVER STUD	2		
21	11	20110	NUT, SHIFT CONTROL LEVER TC	2		
22	54	23568	CLIP, CUT-OUT SEITCH LEAD TO	1		
23	10	21643	SCREW, CUT-OUT SWITCH LEAT	1		
24		22789	"D" WASHER, CLIP ATTACHING	1		
25	10	25299	SCREW, REVERSE LOCK VALVE	2		
26	13	21804	LOCKWASHER, REVERSE LOCK	2		
27		49639A 1	SWITCH ASSEMBLY, CUT-OUT-R	1		
28		45717	SHIELD, CUT-OUT SWITCH	1		
29	10	36003	SCREW, SHIELD AND SWITCH T	2		