



1718

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		863457A 2	THERMOSTAT HOUSING	1		
2	22	32803	PLUG, Pipe (.375-18 Brass)	2		
3		806490T	SENDER, Water Temperature	1		
3		49734	SENDER, Water Temperature	OPT	(Dual Station)	
4	13	26996	LOCKWASHER, (#10)	1		
5	11	68219	NUT, (#10-32)	1		
6		805218T	SENSOR	1		
7	27	806871	GASKET, Thermostat Housing	1		
8		807252T 2	THERMOSTAT, (160 Degree F)	1		
9	23	806922	SLEEVE, Thermostat	1		
10	27	53045 1	GASKET, Lower Thermostat Housin	1		
11	10	40107 75	SCREW, (M8 X 75)	2		
12		12552	LIFTING EYE	1		
13	22	806608A 1	PLUG KIT, Blue	1		
14	25	32509	O-RING, (.489 x .070)	1		
15		864398T 1	THERMOSTAT HOUSING ASSEM	1		
16	27	53045 1	GASKET, Thermostat Housing	1		
17	22	32803	PLUG, Pipe (.375-18 Brass)	2		
18	25	807134 1	SEAL, Thermostat	1		
19	10	40011151	SCREW, (M8 x 35)	2		
20		805218T	SENSOR	1		
21		806490T	SENDER, Temperature	1		
21		49734	SENDER, Temperature	OPT	(Dual Station)	
22	13	26996	LOCKWASHER, (#10)	1		
23	11	68219	NUT, (#10-32)	1		
24		864493	THERMOSTAT, (170 Degree F)	1		
25		807075A 1	COVER, Thermostat Housing	1		
26	22	818390	DRAIN COCK	1		
27	10	29198	SCREW AND LOCKWASHER, (.31	2		
.	27	861246A98	GASKET SET, Engine Overhaul	1		