



A = FUEL LINE FROM FUEL PUMP

12796

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		861260T	INJECTOR, Fuel	8		
2	25	851889	O-RING	16		3
3		860373A 4	INTAKE MANIFOLD	1		
4	27	807473A 1	GASKET SET	1		3
5	22	860075	PLUG, Pipe (.500-14)	2		
6	22	805408	VALVE, Rail Pressure Service	1		
7	22	805515	CAP, Brass	1		
8	10	808010	SCREW, (.3125 X 1.375)	8		
9		861804T 1	FUEL RAIL	2		
10	10	86885	SCREW, (.250-20 x 1.500) SS	4		
11		861805	TUBE, Fuel Cross Over	2		
12	22	73379	PLUG, (.250-18)	2		
13	22	32802 2	PLUG, Pipe (.125-27) Brass	1		
14		807399T	SENSOR, Fuel Pressure	1		
15	22	33821	CONNECTOR	1		
16		861249A 1	MANIFOLD AIR PRESSURE SENS	1		
17		805223T	SENSOR	1		
18		861198	CLIP	1		
19	10	806826	SCREW, (#8-32 X .25)	1		
20	25	862053	O-RING	8		
.	27	75611A98	GASKET SET, Engine Overhaul	1		