



- A - Audio Warning Components**  
 1- Oil Pressure Switch  
 2- Drive Unit Oil Level
- B - Instrumentation Components**  
 1- Oil Pressure Sender  
 2- Water Temperature Sender  
 3- Trim Sender
- C - Charging and Starting Components**  
 1- Alternator  
 2- Ground Stud  
 3- Starter  
 4- Circuit Breaker  
 5- Starter Slave Solenoid
- a- Positive Power Wire To EFI System Harness  
 b- Harness Connector To EFI System Harness  
 c- Auxiliary Tachometer Lead

19359

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	84	861819T 1	WIRING HARNESS, Engine	1	(Use With Mando Alternator With \	
-	84	862179T 1	WIRING HARNESS, Engine	1	(Use With Delco Alternator With M	