



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1623	8951A43	GEAR HOUSING ASSEMBLY, CO	1		
1	1623	8951A37	GEAR HOUSING ASSEMBLY BL	1		
53		76865	SHIFT CRANK	1		
54	18	46950	COTTER PIN	1		5
55		NSS	ADJUSTING SLEEVE	1	(Replacement Spool Assembly 81E	
56		NSS	RETAINER	1	(Replacement Spool Assembly 81E	
57		NSS	WASHER	2	(Replacement Spool Assembly 81E	
58		NSS	SPRINGER	1	(Replacement Spool Assembly 81E	
59		NSS	SPOOL	1	(Replacement Spool Assembly 81E	
60		NSS	SHAFT	1	(Replacement Spool Assembly 81E	
61	15	47397A	SHIM	AR		7,8,9
62	31	35928T	TAPERED ROLLER BEARING A	1		5,7,8,9
63		NSS	FORWARD GEAR	1		7
64	31	42679	ROLLER BEARING (TORRING	AR		8,9
64	31	30895T	ROLLER BEARING (TORRING	AR		5,7,8,9
65	52	853594T	CLUTCH	1		9
66	17	30632	CROSS PIN	1		
67	24	30893	SPRING	1		
68	44	824110	PROPELLER SHAFT	1		
69	43	824109A	REVERSE GEAR	1		7,9
70		68100	THRUST RING	1		
71	30	88957T	BALL BEARING	1		7,8,9
72	25	31534	O-RING	1		3,8,9
73		73020A14	CARRIER ASSY (CASTING #73	1		
73		818763A10	CARRIER ASSY. (CASTING #73	1		
74	31	30956T	ROLLER BEARING	1		7,8,9
75	26	76868	OIL SEAL	2		3,8,9
75	26	14077	OIL SEAL (INSIDE) CUTTER SE	1		
75	26	12224	OIL SEAL (OUTSIDE) CUTTEF	1		3,8,9
76	28	30281	KEY	1		
77	14	79447	TAB WASHER (USE WITH 7302	1		8,9
77	14	18323	TAB WASHER (USE WITH 7302	1		8,9
78		79448	COVER	1		
79	12	835467	THRUST HUB (FOR USE W/"BLA	1		
79		56292A	THRUST HUB (FOR USE W/M/C	1		
80	12	31211A	WASHER, SPLINED	1		
81	14	816629	TAB WASHER	1		
82	11	52707Q	NUT	1		
83		31640Q	TRIM TAB ASSEMBLY (2-3/8")	1		
83		34127T	TRIM TAB ASSEMBLY (4")	OPT	THIS TRIM TAB CANNOT BE US	
84	10	22470	SCREW (1.24")	1		