



M0028-K14

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
--		14336A20	HYDRAULIC PUMP ASSEMBLY	1		
1		41217T	ADAPTOR	1		
2		803852	COUPLING	1		
3		803853A 1	MANUAL RELEASE (INCLUDE	AR		
3		96598A 1	MANUAL RELEASE (INCLUDE	AR		
4		41216	PUMP (INCLUDES SCREWS)	1		
5	35	89496	FILTER	2		
6	25	89498	"O" RING, MOTOR END	1		
7	25	89497	"O" RING, RESERVOIR END	1		
8		41218	DIPSTICK	1		
9		41219T	RESERVOIR	1		
10	10	41220	SCREW, RESERVOIR (INCLUDE	1		
11	16	41222	THUR STUD (SHORT)	1		
11	16	41221	THRU STUD (LONG)	1		
--		17649A 1	MOTOR, HYDRAULIC PUMP	1		
12		89484	END FRAME, DRIVE END	1		
13		41214	ARMATURE	1		
14	12	89482	WASHER, THRUST - ARMATI	1		
15		41215	FIELD AND FRAME	1		
16		89487	BRUSH CARD	1		
17		89488	END FRAME, COMMUTATOR	1		
18	10	41212	THRU BOLT, MOTOR (SHOR	1		
18	10	41213	THRUST BOLT, MOTOR (LON	1		
19	11	89481	NUT, THRU BOLT AND STUD	6		
-	19	11005A 1	TRAIL-OUT VALVE PLUG	-		
-		99073A 1	OVERHAUL REPAIR KIT	-		
-		95353A 1	THERMAL RELIEF VALVE KIT	-		
-		812499A 1	DOWN PRESSURE RELIEF VALV	-		
-		812498A 1	UP PRESSURE RELIEF VALVE KI	-		