



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		62952T	TRANSOM PLATE	1		
2	22	47902	VENT, OIL RESERVOIR	1		
3		54244A 1	COVER ASSEMBLY, OIL RESERV	1		
4	27	54307	GASKET, OIL RESERVOIR COVER	1		
5	10	54523	SCREW, OIL RESERVOIR COVEF	8		
6		55083	DIPSTICK, OIL LEVEL - OIL RESE	1		
7	12	34876	WASHER GIMBAL HOUSING STL	8		
8	11	35000	NUT, GIMBAL HOUSING STUD	8		
9		54234	COVER, EXHAUST	1		
10		55897	SEAL, EXHAUST COVER	1		
11	10	20639	SCREW, EXHAUST COVER (1-1/8	15		
12	11	29250	NUT, EXHAUST COVER SCREW	15		
13	10	35386	SCREW, EXHAUST COVER - BOT	2		
14	22	34982	CONNECTOR, TRANSOM PLATE	1		
-		79430	PLATE, EXHAUST TUBE BLOCK-I	2		
-		99940A 1	CONTINUITY KIT (COMPONENTS	1		