



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		830401262	ALTERNATOR ASSEMBLY	1		
1		834101600	STATOR ASSEMBLY	1		
2		833871170	INSULATOR-TERMINAL B	1		
3		833871160	INSULATOR-TERMINAL B	2		
4		830105040	NUT	4		
5	11	830106050	NUT	2		
6		833551180	CONDENSER-ALTERNATOR	1		
7		833871150	INSULATOR-TERMINAL B	1		
8		834451190	CLAMP	1		
9		833511020	BUSH-FRAME	1		
10		833591810	FRAME-RECTIFIER END	1		
11		833781600	INSULATOR-TERMINAL	1		
12		833651080	WIRE-LEAD	1		
13		833641450	BOLT-TERMINAL	1		
14		837001520	REGULATOR ASSEMBLY-GEN	1		
15		833561220	HOLDER-W/RECTIFIER	1		
16		833711170	BRUSH-ALTERNATOR (A)	2		
17		833761030	HOLDER-BRUSH (B)	2		
18		833101510	FRAME ASSEMBLY-ALTERNAT	1		
19		833121520	PLATE-RETAINER	1		
20		833621090	BOLT-THROUGH	3		
21		833171440	BOLT-THROUGH	3		
22		834121140	COLLAR-SPACE	1		
23		832521630	BEARING	1		
24		834121150	COLLAR-SPACE	1		
25		833301530	ROTOR ASSEMBLY-ALTERNAT	1		
26		833331030	RING-SPACE	1		
27		832521640	BEARING	1		
28		831016080	NUT-LOCK	1		
29		839016480	LOCKWASHER	1		
30		834311380	PULLEY-ALTERNATOR	1		
31		834411170	FAN-ALTERNATOR	1		