



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		835601760	PUMP ASSEMBLY-FUEL FEED	1		
1		835651240	ROD-FEED PUMP PUSH	1		
2		835661010	PISTON-FEED PUMP	1		
3	24	835671050	SPRING-FEED PUMP PISTON	1		
4		835211030	PLUG-SCREW	1		
5	27	838431220	GASKET	1		
6		835681050	TAPPET-FEED PUMP	1		
7		835681230	TAPPET-FEED PUMP	1		
8		835711050	PIN-FEED PUMP TAPPET ROI	1		
9		835721030	BLOCK-FEED PUMP TAPPET	2		
10		835631060	VALVE-FEED PUMP CHECK	2		
11	24	835621010	SPRING-FEED PUMP CHECK V	2		
12		835731010	CONNECTOR	1		
13		838131460	O RING	1		
14		838131460	O-RING	1		
15		835681100	TAPPET-FEED PUMP	1		
16		835091180	COVER-PRIMING PUMP	1		
17	10	838311630	BOLT-JOINT	1		
18	10	838311210	BOLT-JOINT	1		
19	12	835914104	WASHER-SOFT	2		
20	12	835914104	WASHER-SOFT	2		