



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		839108251	BOLT	2	
2		831134130	PIPE-INTAKE	1	
3	25	835160102	O RING	1	
4	32	830233438	HOSE-AIR	1	
5		836970103	CLAMP	4	
6		833001280	INTERCOOLER ASSEMBLY (SEE	1	
7	32	830233363	HOSE-AIR	1	
8		836945101	CLAMP	2	
10	10	831110301	BOLT	6	
11	10	830114300	BOLT	1	
12	25	837212061	GROMMET	2	
13		833021103	BRACKET ASSEMBLY-INTERCOC	1	
14	10	839108302	BOLT	3	
15		830116221	SPACER	1	
16		839042660	CLIP ASSEMBLY	1	
17		832217120	PLUG	1	
18		830231201	PIPE ASSEMBLY-COOLANT PUMI	1	
19	11	830108070	NUT	3	
20	13	839008200	LOCKWASHER	2	
21		836008140	WASHER-PLAIN	2	
22		839042660	CLIP ASSEMBLY	1	
23		839110301	BOLT	1	
24		832691140	BRACKET-COOLANT BY-PASS PII	1	
25		836945101	CLAMP	1	
26	32	830234443	HOSE-WATER	1	
27	54	836958103	CLAMP	1	
28	25	835131103	O RING	1	
29		831010250	BOLT	2	
30		831110201	BOLT	1	
31		831071450	PIPE ASSEMBLY-OIL OUTLET	1	
32	10	831110251	BOLT	2	
33	27	831351070	GASKET-OIL (OUTLET)	1	
34		831002630	TURBOCHARGER ASSEMBLY (SE	1	
35	11	830910141	NUT	6	
36	11	830910142	NUT	6	
37	25	835113103	O RING	1	
40	12	836008240	WASHER-PLAIN	2	
41		839041380	CLIP ASSEMBLY	1	
42		839934720	HOLDER-CLIP	1	
43		838908110	BOLT	1	
44	27	831791090	GASKET	1	