



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		831001350	TURBOCHARGER ASSEMBLY	1		
1		831501140	ROTOR ASSEMBLY	1		
2		831151320	ROTOR	1		
3		831161080	THROWER-Oil	1		
4		831221080	BUSHING	1		
5		831241200	SEAL-Ring	1		
6		831241190	SEAL-Ring	1		
7		831241270	SEAL-Ring	1		
8		831171250	NUT	1		
9		831181200	IMPELLER-Blower	1		
10		831271160	PLATE-Back	1		
11		831311160	BEARING	2		
12		831431140	BEARING-Thrust	1		
13		831141130	CASE-Blower	1		
14		831451240	BOLT	6		
15		831231220	PLATE	6		
16		831111440	CASE-Turbine	1		
17		831451190	BOLT	6		
18		831211260	CASE-Bearing	1		
19		831321110	RING-Nozzle	3		
20		831361120	SCREW	4		
21		831361130	SCREW	21		
22		831411140	PROTECTOR-Heat	1		
23		831231270	PLATE	6		

