



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	837	2756A 2	CYLINDER BLOCK AND CRANKC	1		
2	21	28481A 1	CHECK VALVE ASSEMBLY, CRA	1		
3	19	56688	WELCH PLUG, CYLINDER BLO	1		
4	16	33526	STUD, BLOCKE AND CRANKCA	6		
5	16	21723	STUD, CARBURETOR MOUNTI	2		
6	17	21438	PIN, DOWEL - CRANKCASE TO	2		
7	22	25885	ELBOW, TELL TALE - CYLINDE	1		
8	10	31294	SCREW, CRANKCASE TO CYLIN	8		
9	10	24624	SCREW, CRANKCASE TO CYLIN	2		
10	11	46887	NUT, CRANKCASE FASTENING S	10		
11	10	26801	SCREW, MAIN BEARING LOCKI	1		
12	14	20091	TAB WASHER, MAIN BEARING LI	1		
13	15	31412A 1	SHIM, UPPER HOUSING TO CYLI	AR		
14	1141	3971A 1	BEARING HOUSING ASSEMBLY,	1		
15	30	20861	BEARING, BALL - UPPER BEAR	1		
16	31	31410	BEARING, FOLLER - UPPER BE	1		
17	26	56741	OIL SEAL, UPPER BEARING HC	1		
18	25	20863	"O" RING, UPPER BEARING HC	1		4
19	10	28707	SCREW, UPPER BEARING HOUS	4		
20	27	31434	GASKET, TRANSFER PORT COVI	1		4
21		31430	COVER, TRANSFER PORT	1		
22	10	20665	SCREW, PORT COVER TO CYLIN	3		
23	1019	3944	COVER, CYLINDER BLOCK	1		
24	27	31436	GASKET, CYLINDER BLOCK	1		4
25	10	21091	SCREW, CYLINDER BLOCK COVE	6		
26	11	46887	NUT, CYLINDER BLOCK COVER	6		
27	27	46233	GASKET, CYLINDER BLOCK TO E	1		4
28		46235	(LATE, BAFFLE - EXHAUST MANI	1		
29	27	46233	GASKET, BAFFLE PLATE TO EXH	1		4
30		46172	COVER, EXHAUST MANIFOLD	1		
31	10	28668	SCREW, BAFFLE PLATE AND MA	8		
32		30212	TERMINAL BLOCK, EXHAUST MA	1	SERIAL #2798057-02938830	
33	10	35519	SCREW, TERMINAL BLOCK TO E	2	SERIAL #2798057-02938830	
34	10	30663	SCREW, MAGNETO GROUND LE	1	SERIAL #2798057-02938830	
35	30	20861	BEARING, BALL - CRANKCASE (L	1		
36	26	56397	OIL SEAL, CRANKCASE (LOWER)	1		
37	10	23015	SCREW, ADJUSTING - THROTTL	1		
38	11	20645	NUT, THROTTLE CONTROL ADJI	1		