



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	22339	NUT, FLYWHEEL	1,1		
2	12	36281	WASHER, FLYWHEEL NUT	1,1		
3	25	37340	"D" RING, FLYWHEEL HUB	1,1		4
4	28	20094	KEY, FLYWHEEL DRIVE	1,1		
5	221	3347A 1	FLYWHEEL ASSEMBLY, COMPLE	1,1		
6	10	35563	SCREW, FLEXIBLE PLATE TO F	6,6		
7	50	33000A 1	RATCHET ASSEMBLY, FLYWHE	1,1		
8	10	32417	SCREW, RATCHET TO FLYW	6,6		
9	10	34290	SCREW, RATCHET TO FLYW	2,2		
10	13	26992	LOCKWASHER, RATCHET TC	2,2		
11	398	3297A 1	STATOR PLATE ASSEMBLY, CON	1,1	FOR ADDITIONAL PARTS OF A	
12		48033A 1	SHIELD ASSEMBLY, LEAD WIR	1,1		
13	10	49049	SCREW, LEAD WIRE SHIELD	2,2		
14	54	39844	CLIP, STATOR LEADS TO STAT	1,1		
15	10	35400	SCREW, STATOR LEADS CLIP	1,1		
16		22789	"D" WASHER, STATOR LEADS	1,1		
17	11	24656	NUT, STATOR LEADS SCREW	1,1		
18		34601	RING, HOLD DOWN - STATOR	1,1		
19	10	35400	SCREW, HOLD DOWN RING TC	4,4		
20	15	33910015	SHIM, STATOR PLATE TO CRANI	2,2		
21		46381	BRACKET, STATOR PLATE	1,1		
22	10	34436	SCREW, BRACKET TO STATOR F	2,2		
23		46407	LINK ROD, THROTTLE CONTROL	1,	SERIAL 00000000-02432535	
23		52581	LINK ROD, THROTTLE CONTROL	1,1	SERIAL 02432536-09999999	
24	12	30164	WASHER, LINK ROD SWIVEL TO	1,1		
25		33973	SWIVEL, LINK ROD TO THROTTL	1,1		
26	11	45812	NUT, THROTTLE CONTROL LINK	2,2		
27		45559	TERMINAL BLOCK, STATOR PLA	1,1		
28	10	28192	SCREW, TERMINAL BLOCK TO R	2,2		
30		53203	GROUND STRAP, STATOR PLAT	1,1		
31	54	22627	CLIP, STATOR LEADS FASTENIN	2,2		
31	54	26550	CLIIP, STATOR LEADS FASTENIN	1,1		
32	10	30663	SCREW, STATOR LEADS FASTE	2,2		
33		22789	"D" WASHER, STATOR LEADS F	2,2		