



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		39323	HANDLE, NYLON - SHIFT CONTR	1,1		
2	12	29245	WASHER, SHIFT CONTROL HAN	1,1		
3	11	39305	NUT, SHIFT CONTROL HANDLE	1,1		
4		39399	BRACKET, MOUNTING - SHIFT SI	1,1		
5	10	22421	SCREW, MOUNTING BRACKET T	2,2		
6	11	46887	NUT, MOUNTING BRACKET SCR	2,2		
7	24	39627	SPRING, DETENT - MOUNTING E	1,1		
8		39601	PLATE, DETENT SPRING	1,1		
9	10	20100	SCREW, PLATE AND SPRING TO	2,2		
10	23	30678	BUSHING, NYLON - SHIFT SHAFT	2,2		
11		39588	CAM, DETENT - SHIFT SHAFT	1,1		
12	17	25905	PIN, ROLL - DETENT CAM TO SH	1,1		
13	13	36206	WASHER, WAVE - SHIFT SHAFT	1,1		
14		39415	LEVER, SHIFT CONTROL	1,1		
15	17	25909	PIN, ROLL - SHIFT CONTROL LEV	1,1		
16		39632	SHAFT, SHIFT (HORIZONTAL)	1,1		
17	15	39952A 1	SHIM, SECTOR GEAR TO NYLON AR			
18	43	33994	GEAR, SECTOR - SHIFT SHAFT	1,1		
19	12	29245	WASHER, SHFIT SHAFT	1,1		
20	11	20361	NUT, SECTOR GEAR TO SHIFT S	1,1		
21		39398A 1	SHIFT CONTROL SHAFT ASSEMB	1,1		
22	43	39477	GEAR, SECTOR - SHIFT CONTE	1,1		
23	25	38933	"O" RING, SHIFT CONTROL SHAI	1,1		
24	23	30677	BUSHING, NYLON - SHIFT CONTI	1,1		4
25		46836	FOLLOWER NEUTRAL SPEED LIM	1,1		
26	10	24644	SCREW, FOLLOWER TO POWER	1,1		
27	15	28212010	SHIM, LIMITER FOLLOWER SCRE	1,1		
28	11	46887	NUT, LIMITER FOLLOWER SCRE	1,1		
29	24	39675	SPRING, NEUTRAL SPEED LIMIT	1,1		
30	10	30663	SCREW, SPRING TO LIMITER FO	1,1		
31		46837	STOP, OVER-SPEED LIMITER	1,1		
32	12	24676	WASHER, LIMITER STOP SCREW	1,1		
33	10	46898	SCREW, LIMITER STOP TO FOLL	1,1		