



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1	2130	3207A 2	TOP COWL ASSEMBLY	1,1			
2		39664	INSERT, ROPE GUIDE - TOP COWL	1,1			
3	16	21553	STUD, TOP COWL TO MOUNTING	3,3			
4	12	30283	WASHER, TOP COWL STUD	AR,			
5	11	21528	NUT, TOP COWL STUD	3,3			
6		39400	SHIELD, REAR - TOP COWL	1,1			
7	10	20646	SCREW, REAR SHIELD TO TOP COWL	3,3			
8	2133	2706A 5	WRAP AROUND COWL ASSEMBLY	1,1			
9		39606	BLANKER, SOUND ABSORBING	1,1			
10		46785A 1	COWL LATCH ASSEMBLY	2,2			
11		30413	HOOK, COWL LATCH FASTENING	2,2			
12		39628	BUTTON, FRONT COVER RELEASE	1,1			
13	24	20099	SPRING, COMPRESSION - FRONT COVER	1,1			
14	12	29245	WASHER, FRONT COVER RELEASE	1,1			
15		39493	CATCH, FRONT COVER RELEASE	1,1			
16	10	22523	SCREW, FRONT COVER LATCH	2,2			
17	2127	2666A 4	FRONT COVER ASSEMBLY, COMPLETE	1,1			
17	2127	2666A 7	FRONT COVER ASSEMBLY, COMPLETE	1,1			
18		39505	BASE, FRONT COVER LATCH	1,1			
19	10	26500	SCREW, LATCH BASE TO FRONT COVER	2,2			
20	12	26014	WASHER, LATCH BASE SCREW	AR,AR			
21		39482	HOOK, FRONT COVER LATCH	1,1			
22	24	39598	SPRING, TORSION - FRONT COVER	1,1			
23	17	39599	PIN, PIVOT - FRONT COVER LATCH	1,1			
24		39936	BLANKER, SOUND ABSORBING	1,1			
25		46904	HOUSING, STARTER	1,1			
26	10	37562	SCREW, STARTER HOUSING TO FRONT COVER	1,1			
27	13	26421	LOCKWASHER, STARTER HOUSING	1,1			
28	10	24644	SCREW, STARTER HOUSING TO FRONT COVER	1,1			
28	10	22659	SCREW, STARTER HOUSING TO FRONT COVER	1,1			
29	11	20361	NUT, STARTER HOUSING TO FRONT COVER	2,2			
30		47430	BUMPER, RUBBER - STARTER HOUSING	1,1			
31		30976	PULLEY, STARTER CABLE	1,1			
32	10	37892	SCREW, PULLEY TO STARTER HOUSING	1,1			
33	12	22887	WASHER, PULLEY SCREW	1,	SERIAL 00000000-02439399		
33		53111	RETAINER, PULLEY SCREW	1,1	SERIAL 02439400-09999999		
34	23	30977	SPACER, PULLEY SCREW	1,1			
35	11	20110	NUT, PULLEY SCREW	1,1			
36	14	20165	TAB WASHER, SHEAVE SHAFT (LEFT HAND)	1,1			
37	11	20166	NUT, SHEAVE SHAFT (LEFT HAND)	1,1			
38		20165	RETAINER, STARTER SPRING	1,1			