



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	3311	818639A 1	TOP CARBURETOR	1	WMH-19	
1	3311	818639A 2	CENTER CARBURETOR	1	WMH-19	
1	3311	818639A 3	BOTTOM CARBURETOR	1	WMH-19	
1	3311	818639A 6	TOP CARBURETOR	1	WMH-46	
1	3311	818639A10	CENTER CARBURETOR	1	WMH-46	
1	3311	818639A 8	BOTTOM CARBURETOR	1	WMH-46	
1	3311	818639A12	TOP CARBURETOR	1	WMH-47	
1	3311	818639A13	CENTER CARBURETOR	1	WMH-47	
1	3311	818639A14	BOTTOM CARBURETOR	1	WMH-47	
2		810779	LIMITER CAP	6		
3			IDLE NEEDLE/SPRING	6		8
4	27	67751 1	GASKET	3		4,10
5		815633060	JET-PROGRESSION AIR (.060)	6	(WMH-19/46)	
5		815633050	JET-PROGRESSION AIR (.050)	6	(WMH-47)	
6	1395	6030	JET-IDLE AIR BLEED (.070)	3		
7	1395	6246	JET-IDLE AIR BLEED (.048)	3		
8	1395	9596	PLUG	15		
9			GASKET-PLUG	15		8,10
10			SPRING-THROTTLE RETURN	3		8
11		810721	THROTTLE LEVER	2	(TOP/BOTTOM)	
11		810722	THROTTLE LEVER	1	(CENTER - WMH-19)	
11		810722 1	THROTTLE LEVER	1	(CENTER - WMH-46/47)	
12	1395	811284	SPACER	3		
13	12	810745	WASHER	3		
14	11	810744	NUT	3		
15			GASKET-FUEL BOWL	3		8,10
16		810738	FLOAT	3		
17			SCREW-FLOAT PIN	3		8
18		F10064	FLOAT SHAFT	3		8
19	1395	811690	VALVE SEAT KIT	3		
20			GASKET-VALVE SEAT	3		8,10
21	1395	823628	FUEL BOWL (TOP)	1		
21	1395	823624	FUEL BOWL (CENTER/BOTTOM)	2		
22	1395	6680	JET-MAIN FUEL (.078 - PORT)	3	WMH-19	
22	1399	3794	JET-MAIN FUEL (.074 - STBD.)	AP	WMH-19	5
22	1399	3796	JET-MAIN FUEL (.076 - STBD.-E)	1	WMH-19	
23	1399	5132	SCREW-FUEL BOWL	18	WMH-19	8
24	1395	823630	JET-PROGRESSION FUEL	6	WMH-19	
22	1399	3794	JET-MAIN FUEL (.074 - PORT/S)	2	WMH-46	
22	1399	3794	JET-MAIN FUEL (.074 - STBD. -I)	2	WMH-46	
22	1399	3796	JET-MAIN FUEL (.076 - PORT)	2	WMH-46	