



1325

| Parts List | | | | | | |
|------------|-------|-----------|----------------------------------|-----|-----------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 0 | 1623 | 859399T16 | GEAR HOUSING ASSEMBLY, Con | 1 | [X-Long] | |
| 0 | 1623 | 859399T17 | GEAR HOUSING ASSEMBLY, Con | 1 | [XX-Long] | |
| 1 | 1623 | 859399T18 | GEAR HOUSING, Basic | 1 | | |
| 2 | 22 | 859403 | PLUG | 1 | | |
| 3 | | 823903 | SHIFT CRANK | 1 | | |
| 4 | | 19755T 7 | SPOOL ASSEMBLY | 1 | | |
| 5 | | NSS | NOT SOLD SEPARATE, Spool | 1 | | |
| 6 | | NSS | NOT SOLD SEPARATE, Sleeve | 1 | | |
| 7 | 18 | 46950 1 | COTTER PIN | 1 | | |
| 8 | 15 | 44491A 1 | SHIM SET | AR | | |
| 9 | | 828830A 2 | BEARING ADAPTOR ASSEMBL' | 1 | | |
| 10 | 31 | 814653T | ROLLER BEARING | 1 | | |
| 11 | 12 | 815481 | THRUST WASHER, | 1 | | |
| 12 | 31 | 815480 | BEARING, Thrust | 1 | | |
| 13 | 43 | 828696T 2 | GEAR, Reverse (12/21) | 1 | | |
| 14 | 31 | 15844 | BEARING ASSEMBLY, Roller | 1 | | |
| 15 | 24 | 30893 | SPRING | 1 | | |
| 16 | 52 | 859340T | CLUTCH | 1 | | |
| 17 | 17 | 30632 | PIN, Cross | 1 | | |
| 18 | 17 | 828356 | PIN, Detent | 1 | | |
| 19 | 44 | 824111 | SHAFT, Propeller | 1 | | |
| 20 | 43 | 828695A 1 | GEAR SET, Forward/Pinion (12/21) | 1 | | |
| 21 | 23 | 17615 14 | SPACER SHIM, (.206) | AR | | |
| 21 | 23 | 17615 15 | SPACER SHIM, (.208) | AR | | |
| 21 | 23 | 17615 16 | SPACER SHIM, (.210) | AR | | |
| 21 | 23 | 17615 17 | SPACER SHIM, (.212) | AR | | |
| 21 | 23 | 17615 18 | SPACER SHIM, (.214) | AR | | |
| 21 | 23 | 17615 19 | SPACER SHIM, (.216) | AR | | |
| 21 | 23 | 17615 20 | SPACER SHIM, (.218) | AR | | |
| 21 | 23 | 17615 21 | SPACER SHIM, (.220) | AR | | |
| 21 | 23 | 17615 22 | SPACER SHIM, (.222) | AR | | |
| 21 | 23 | 17615 23 | SPACER SHIM, (.224) | AR | | |
| 21 | 23 | 17615 24 | SPACER SHIM, (.226) | AR | | |
| 21 | 23 | 17615 25 | SPACER SHIM, (.228) | AR | | |
| 21 | 23 | 17615 26 | SPACER SHIM, (.230) | AR | | |
| 22 | 31 | 815480 | BEARING, Thrust | 1 | | |
| 23 | 12 | 815481 | THRUST WASHER, | 1 | | |
| 24 | | 828831A 3 | BEARING ADAPTOR ASSEMBL' | 1 | | |
| 25 | 31 | 814653T | ROLLER BEARING | 1 | | |
| 26 | 12 | 18448 | THRUST WASHER | 2 | | |
| 27 | 31 | 15844 | BEARING, Thrust | 2 | | |