



14521

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	3406	9622T 6	BRACKET, Clamp (Starboard)	1		
2	3406	9623 1	BRACKET, Clamp (Port)	1		
3	10	95373	BOLT	1		
4	12	95375	WASHER	2		
5	12	16192	WASHER	1		
6	11	815088	NUT, (M8)	1		
7		16193 1	DISTANCE PLATE	1		
8	10	16194	SCREW	2		
9	24	16212	SPRING	1		
10		825112A 3	TILT STOPPER	1		
11		16208 1	GRIP	1		
12	10	16211 1	BOLT	2		
13		16210	SET PLATE	1		
14		825113	BUSHING	2		
15	10	16200	CLAMP SCREW ASSEMBLY	2		
16	12	95379	PAD	2		
17		16198	THRUST ROD	1		
18	24	815093 1	SPRING	1		
19	24	16195 1	SPRING	1		
20	12	16197	WASHER	1		
21	10	16196	SCREW	1		
22	3407	813029T 9	SWIVEL BRACKET, Front	1		
23	3407	883300T	SWIVEL BRACKET, Rear	1		
24	23	803567 4	BUSHING, Lower	1		
25		883301	FRICITION BAND	1		
26	11	883302	WING NUT	1		
27	12	95392 1	WASHER	1		
28	24	95383 9	SPRING	1		
29		803582	THRUST PLATE	1		
30	23	803567 2	BUSHING, Upper	1		
31		803582 1	THRUST PLATE	2		
32	10	823042 22	BOLT	4		
33	22	824969	FITTING, Grease	2		
34		16213 3	REVERSE LOCK ARM	1		
35	10	823042 23	BOLT	2		
36	24	16216	SPRING	1		
37	24	16215	SPRING	1		