



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		78551A 5	STEERING HANDLE ASSEMBLY	1		
1		48405	ARM, STEERING HANDLE	1		
2	12	21631	WASHER, STEERING HANDLE	1		
3	11	20664	NUT, STEERING HANDLE ARM	1		
5		58192A 1	GRIP, STEERING HANDLE ARM	1		
6		48416	CAP, STEERING HANDLE GRIP	1		
7		48519	PLATE, COVER - DRIVE WHEEL	1		
8	27	48518	GASKET, COVER PLATE	1		
9	10	28192	SCREW	4	DRIVE WHEEL COVER PLATE F.	
10		48414	HOUSING	1	DRIVE WHEEL - STEERING ARM	
11		48516A 1	DRIVE WHEEL AND ROD ASSE	1		
12		48520	CABLE, THROTTLE	1		
13		78551 1	CONDUIT, CABLE	1		
14		89613	CONNECTOR, CONTROL LINKA	1		
15		89566	TUBE, THROTTLE CABLE GUID	1		
15A	10	89601	SCREW, SET - THROTTLE CAB	1		
16		29880	GUIDE, THROTTLE CABLE	1		
17		20007	ANCHOR, THROTTLE CABLE	1		
18	10	20518	SCREW, THROTTLE CABLE AN	2		
19		48521	SHIFT LEVER	1		
20		37813	KNOB, SHIFT LEVER	1		
21	23	48475	BUSHING, NYLON - SHIFT ROD	1		
22	12	35950	WASHER, SHIFT ROD	1		
23	18	25191	COTTER PIN, SHIFT ROD	2		
24		49563	ROD, SHIFT	1		
25		48419	ROD END, SHIFT ROD	1		
26		78812A 1	DETENT, SHIFT LEVER	1		
27	10	48409	SCREW	2	SHIFT LEVER DETENT TO STEE	
28	23	48237	BUSHING, NYLON - SHIFT LEV	1		
29	12	37828	WASHER, SHIFT LEVER	1		
30	11	34863	NUT, SHIFT LEVER TO STEERI	1		
31		48404	BRACKET, STEERING HANDLE	1		
32		48416	CAP, STEERING HANDLE BRAC	1		
33	10	48476	SCREW HANDLE BRACKET TO	1		
34	12	48477	WASHER, STEERING HANDLE	1		
35	12	48526	WASHER	1	NYLON - STEERING HANDLE BF	
36	23	28919	BUSHING	2	NYLON - STEERING HANDLE BF	
37	23	48525	SPACER, STEERING HANDLE E	1		
38	12	48527	WASHER	1	NYLON - STEERING HANDLE BF	
39	13	48478	WAVE WASHER, STEERING HA	2		
40	12	48526	WASHER	1	NYLON - STEERING HANDLE BF	