



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		39184A	2 STEERING HANDLE ASSEMBLY	1,1		
-		47919A	4 STEERING HANDLE ASSEMBLY	1	SERIAL 00000000-#2380027	
-		49556A	2 STEERING HANDLE ASSEMBLY	1	SERIAL #2380028-09999999	
1		27763	GRIP, RUBBER - STERING HAN	1,1		
2		35909	BODY AND SHAFT, STEERING	1,1		
3		31001	INDICTOR, SPEED AND LIMIT	1,1		
4	10	31002	SCREW, SET - SPEED AND SHI	1,1		
5	10	22290	SCREW, DRIVE - INDICATOR T	1,1		
6	23	30677	BUSHING NYLON - STEERING I	1,1		
7		39184A	1 STEERING HANDLE ASSEMBL	1,1		
7		47919A	3 STEERING HANDLE ASSEMBL	1	SERIAL 00000000-#2380027	
7A		49556	HANDLE, STEERING	1	SERIAL #2380028-09999999	
7B		49558	KNUCKLE, STEERING HANDLE	1	SERIAL #2380028-09999999	
7C	23	49555	BUSHING, RUBBER - STEERING	1,1	SERIAL #2380028-09999999	
8	23	28100	BUSHING, NYLON - STEERING	1,1		
9	12	30283	WASHER, STEERING HANDLE	1,1		
10	24	26703	SPRING, STEERING HANDLE S	1,1		
11		39211	RETAINER, YOKE PIN HOLDING	1,1		
12		39208	YOKE, STEERING HANDLE SHA	1,1		
13	17	26862	PIN, YOKE TO STEERING HAN	1		
14	43	47765	GEAR, BALL - STEERING HANC	1		
15	17	26862	PIN, BALL GEAR TO STEERING	1		
16	53	47821	RING, RETAINING - BALL GEAF	1,1		
17		39218	PIVOT, STEERING HANDLE TO B	2,2		
18	15	26707	SHIM, STEERING HANDLE PIVOT	3,3		
19	13	39227	WASHER, WAVE - STEERING HA	3,3		
20	13	39228	LOCKWASHER, STEERING HANC	2,2		
21	10	46923	SCREW, STEERING HANDLE TO	2,2		
22		39046A	1 THROTTLE CONTROL SHAFT AS	1,1		
17		48003	PIVOT, STEERING HANDLE TO B	2		
18	15	48002015	SHIM, STEERING HANDLE PIVOT	2		
21	10	48004	SCREW, STEERING HANDLE TO	1		
22A		47742A	1 UNIVERSAL JOINT ASSEMBLY	1		
23	23	48005	SLEEVE, UNIVERSAL JOINT	1		
24	43	47765	GEAR, BALL - UNIVERSAL JOINT	1		
25	17	26862	PIN, BALL GEAR TO UNIVERSAL	1		
26	53	47821	RING, RETAINING - BALL GEAR	1		
27	10	26774	SCREW, THROTTLE CONTROL S	1,1		
28		39210	PLATE, NYLON - THROTTLE CON	2,2		
29		39185	SHIELD, STEERING HANDLE	1,1		
30		29056	BRACKET, STEERING ARM	1,1		