



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	20696	NUT, FLYWHEEL	1		
2	12	36282	WASHER, FLYWHEEL NUT	1		
3	25	36284	"O" RING, FLYWHEEL HUB	1		4
4	28	20094	KEY, FLYWHEEL DRIVE	2		
5	219	2246A 4	FLYWHEEL ASSEMBLY, COMPLE	1		
6	23	34367	COLLAR, FLYWHEEL DUST SH	1		
7	13	22027	WASHER, WAVE - MAGNETO CA	1		
8	398	2574A 4	STATOR PLATE ASSEMBLY, COM	1		
9		39326A 1	SHIELD ASSEMBLY, STATOR F	1		
10	10	49049	SCREW, SHEILD TO STATOR	2		
11		33904	RING, HOLD DOWN - STATOR	1		
12	10	35400	SCREW, HOLD DOWN RING TO	4		
13	398	2230	CAM, BREAKER	1		
14	15	33910015	SHIM, STATOR PLATE TO UPPE	1		
15	54	39844	CLAMP, STATOR LEAD	1		
16	10	20720	SCREW, STATOR LEAD CLIP TO	1		
17		22789	"D" WASHER, LEAD CLIP SCRE	1		
18		34363A 1	THROTTLE CAM BRACKET ASSE	1		
19	10	53296	SCREW, CAM BRACKET TO STA	2		
20	54	34449	CLIP, THROTTLE CAM BRACKET	1		
21		36000	CAM, THROTTLE	1		
22	10	28707	SCREW, THROTTLE CAM TO CA	2		
23	10	34696	SCREW, CONTROL LEVER TO C	1		
24	13	29720	WASHER, WAVE - CONTROL LEV	1		
25	12	34392	WASHER, CONTROL LEVER SCF	2		
26	11	28656	NUT, CONTROL LEVER SCREW	1		