

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	20696	NUT, FLYWHEEL	1		
2	12	36282	WASHER, FLYWHEEL NUT	1		
3	25	36284	"O" RING, FLYWHEEL NUT	1		4
4	28	20094	KEY, FLYWHEEL DRIVE	2		
5	239	4174A 1	FLYWHEEL ASSEMBLY	1		
6	13	35629	WASHER, WAVE - CAM TENSION	1		
7	336	3928	CAM, BREAKER	1		
8	336	3996A 4	STATOR ASSEMBLY	1	SERIAL 02810637-02958118	
8	336	3996A 7	STATOR ASSEMBLY	1	SERIAL 03016581-09999999	
9	10	57814	SCREW, STATOR TO END CAP (4		
10	336	3979A 1	HOUSING ASSEMBLY, CONTACT	1		
11	336	4318A 3	BREAKER ASSEMBLY, CONTACT	2		
12	10	56266	SCREW, BREAKER TO CONTACT	4		
13		56316A 2	CABLE ASSEMBLY, CONTACT F	1		
13		56317A 1	CABLE ASSEMBLY, CONTACT F	1		
14		38938	BOOT, CABLE	2		
15	336	3989	WICK, CAM WIPER - CONTACT	1		
16	336	3981	INSULATOR, CABLE TO CONTACT	2		
17	11	56325	NUT, CABLE INSULATOR	2		
18	336	3987	HOLDER, CONTACT HOUSING	1	SERIAL 02810637-02958118	
18	336	4429	HOLDER, CONTACT HOUSING	1	SERIAL 03016581-09999999	
19	336	3988A 1	COVER ASSEMBLY, CONTACT HO	1		
20	10	56336	SCREW, COVER TO CONTACT HO	2		
21	12	56077	WASHER, WEAR - CONTACT HO	1		
22	13	56076	WASHER, WAVE - CONTACT HO	1	SERIAL 02810637-02958118	
22	13	59145	WASHER, WAVE - CONTACT HO	1	SERIAL 03016581-09999999	
23	54	26550	CLIP, CONTACT HOUSING AND E	1		
24	10	30663	SCREW, CONTACT HOUSING AN	1		
25		22789	"D" WASHER, CLIP SCREW	1		
26		36000	CAM, THROTTLE	1		
27	10	28707	SCREW, THROTTLE CAM TO CO	2		
28		34361	LINK, THROTTLE	1		
29	10	34696	SCREW, THROTTLE LINK TO TH	2		
30	12	34392	WASHER, THROTTLE LINK SCRE	4		
31	13	29720	WASHER, WAVE - THROTTLE LI	2		
32	11	28656	NUT, THROTTLE LINK SCREW	2		
33		56757A 1	JUMPER WIRE ASSEMBLY, STA	1		
34	10	25256	SCREW, JUMPER WIRE ATTACH	1		
35	336	3955A 1	COIL ASSEMBLY, IGNITION	2	SERIAL 02810637-02958118	
35	336	4409A 1	COIL ASSEMBLY, IGNITION	2	SERIAL 03016581-09999999	
36		56318A 4	JUMPER WIRE ASSEMBLY, COIL	1		

