



| Parts List | | | | | | |
|------------|-------|-------|--------------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 339 | 5209A | STATOR ASSEMBLY | 1 | | |
| 2 | 10 | 66707 | SCREW, STATOR TO END CAP (; | 3 | | |
| 3 | 10 | 35400 | SCREW, STATOR TO END CAP (; | 1 | | |
| 4 | 339 | 6119A | COIL ASSEMBLY (5 1/2" AND 6 3. | 1 | | |
| 4 | 339 | 6120A | COIL ASSEMBLY (1 3/4" AND 3 1. | 1 | | |
| 5 | 54 | 59538 | CLIP, COIL RETAINING | 2 | | |
| 6 | 54 | 65927 | CLIP, COIL RETAINING | 2 | | |
| 7 | 86 | 74474 | TERMINAL BLOCK, STATOR | 1 | | |
| 8 | 10 | 20646 | SCREW, TERMINAL BLOCK TO S | 1 | | |
| 9 | 11 | 46438 | NUT, TERMINAL BLOCK SCREW | 1 | | |
| 11 | 338 | 5286A | TRIGGER HOUSING ASSEMBLY | 1 | | |
| 14 | | 66371 | LINK, TRIGGER HOUSING TO TH | 1 | | |
| 15 | 11 | 65110 | NUT, PUSH - LINK TO TRIGGER | 1 | | |
| 16 | 339 | 5287A | SWITCH BOX | 1 | | |
| 17 | 10 | 69022 | SCREW, SWITCH ATTACHING (1 | 2 | | |
| 18 | 12 | 56681 | WASHER, SWITCH BOX ATTACH | 2 | | |
| 19 | | 61990 | STA-STRAP | 5 | | |
| 20 | 10 | 45218 | SCREW, GROUND LEAD TO CYL | 1 | | |