



Parts List					
Ref	Class	Part	Description	Qty	Footnote
	1666	8833A13	GEAR HOUSING, COMPLETE (SH)	1	
	1666	8833A15	GEAR HOUSING, COMPLETE (LO)	1	
	1666	8833A14	GEAR HOUSING, COMPLETE (SH)	1	
	1666	8833A16	GEAR HOUSING, COMPLETE (LO)	1	
1	1666	8833A17	GEAR HOUSING (BLACK)	1	
1	1666	8833A18	GEAR HOUSING (GRAY)	1	
43	31	41347A 1	ROLLER BEARING	1	
44	43	821924A 1	FORWARD GEAR	1	
45	23	41367	BUSHING	1	
46		813139	CAM FOLLOWER	1	
47	52	821930	CLUTCH	1	
48	17	823951	CROSS PIN	1	
49	24	42204	SPRING	1	
50	44	821929	PROPELLER SHAFT	1	
51	43	821926 1	REVERSE GEAR	1	
52		42144A 3	BEARING CARRIER	1	
53	25	33145	O-RING	1	2,17
54	23	821927	BUSHING	1	
55	26	99325	OIL SEAL	1	
56	26	821928	OIL SEAL	1	
57	10	13403	SCREW	1	
58	10	13402	SCREW	2	
59	48	42522A12	PROPELLER (9" X 9")	1	
59	48	42524A12	PROPELLER (SAILPOWER/SAILK)	1	
60	23	42091 1	SPACER	1	
61	11	13914	PROPELLER NUT	1	
62		821932	THRUST HUB	1	
63		822559	HI-REVERSE THRUST CUP	1	
-	27	42364A92	ENGINE/POWERHEAD GASKET	1	
-	26	41365A 3	DRIVESHAFT HOUSING SEAL KI	1	