



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1		12022A 4	BRACKET ASSEMBLY (MERCUR	1		
1		12022A 5	BRACKET ASSEMBLY (MARINEF	1		
2	79	12012A 1	TACHOMETER ASSEMBLY	1		
3	11	11316 1	NUT	4		
4	16	12782	STUD, BRACKET	2		
5		15126	SPACER	1		
6	14	12080	TAB WASHER	2		
7	11	40020 16	NUT	2		
8		12105	GROMMET	1		
9	84	12649A 2	HARNES ASSEMBLY	1		
10	87	88107	KEY SWITCH (SEE BELOW FOR	1		
11	11	93543	NUT, KEY SWITCH	1		
12		12015	COVER, BRACKET	1		
13	10	72169	SCREW, BRACKET COVER	5		
14	19	12014	PLUG	1		
15	87	11083A 4	STOP SWITCH ASSEMBLY	1		
16		15920A54	LAYNARD	1		
17		12044	RETAINER, STOP SWITCH	1		
18	10	40003 58	SCREW, SHIFT LEVER	1		
19	14	42981	TAB WASHER	1		
20	23	42992 1	BUSHING	2		
21		12021 1	SHIFT LEVER	1		
22		12016A 1	DETENT ASSEMBLY	1		
23	16	58152	STUD, SHIFT LEVER	1		
24		98530	KNOB, SHIFT LEVER	1		
25		49563 1	SHIFT ROD	1		
26		48419	ROD END	1		
27	23	26856	BUSHING	1		
28	12	35950	WASHER, SHIFT ROD	1		
29	18	25191	COTTER PIN, SHIFT ROD	1		
30	87	93479A 7	NEUTRAL START SWITCH	1		
31		12609	BRACKET, PRIMARY	1		
32		12610	BRACKET, SWITCH	1		
33	10	90342	SCREW, SWITCH TO BRACKET	2		
34	11	24832	NUT, SWITCH SCREW	2		
35	10	57583	SCREW, BRACKET TO BRACKET	2		
36	12	20878	WASHER, BRACKET SCREW	2		
37	11	26419	NUT, BRACKET SCREW	2		
-		89491 1	KEY 1A			
-		89491 2	KEY 1B			
-		89491 3	KEY 1C			