



15227

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		12022A13	BRACKET ASSEMBLY, Black	1		
1		12022A14	BRACKET ASSEMBLY, Gray	1		
2		12012A 1	TACHOMETER ASSEMBLY	1		
3	11	11316 1	NUT	4		
4	16	12782	STUD	2		
5		15126	SPACER	1		
6	14	12080	TAB WASHER	2		
7	11	40020 16	NUT	2		
8		12105 1	GROMMET	1		
9	84	12649A 2	HARNES ASSEMBLY	1		
10	87	88107	KEY SWITCH, See Chart For Key	1		
11	11	93543	NUT, Special	1		
12		12015A 1	COVER	1		
13	10	812832	SCREW, (#10-16 x .500)	6		
14	19	12014	PLUG	1		
15	87	11083A 4	SWITCH ASSEMBLY, Stop	1		
16		15920A54	LANYARD ASSEMBLY	1		
17		12044 1	RETAINER	1		
18	10	40003 58	SCREW, (M8 x 50)	1		
19	14	42981	TAB WASHER	AR		
20	23	42992 1	BUSHING	2		
21		12021A 1	SHIFT LEVER, Black	1		
21		12021A 2	SHIFT LEVER, Gray	1		
22	12	815351	WASHER	1		
23	16	58152	STUD, (.375-24 x 1.125)	1		
24		98530	KNOB	1		
25		49563 3	SHIFT ROD	1		
26		48419	ROD END	1		
27	23	26856	BUSHING	1		
28	12	29245	WASHER, (.281 x .500 x .060)	1		
29	18	25191	COTTER PIN	1		
30	87	93479A 7	NEUTRAL START SWITCH	1		
31		12609	BRACKET	1		
32		12610 1	BRACKET	1		
33	10	90342	SCREW, (#4-40 x .630)	2		
34	11	24832	NUT, (#4-40)	2		
35	10	57583	SCREW, (#8-32 x .375)	2		
36	12	20878	WASHER	2		
37	11	26419	NUT, (#8-32)	2		
38	10	40001134	SCREW, (M8 x 25)	2		
39		12015A 2	DETENT SPRING KIT	1		