

DESCRIPTION	SEE SEC.	NOTES
Alternator	961	AD31D, AD31XD, TAMD31D, TMD31D
Extra Alternator: 12V, 130A	1013	AD31D, AD31XD, TAMD31D, TMD31D
Extra Alternator: 24V, 100A	1013B	AD31D, AD31XD, TAMD31D, TMD31D
Extra Alternator: 12V, 50A	931	AD31D, AD31XD, TAMD31D, TMD31D
Extra Alternator: 24V, 25A	931B	AD31D, AD31XD, TAMD31D, TMD31D
Alternator 14V 60A, Components	448	AD31D, AD31XD, TAMD31D, TMD31D
Alternator 14V 50A, Components	1029	AD31D, AD31XD, TAMD31D, TMD31D
Alternator 28V 30A, Components: 849602	1733	AD31D, AD31XD, TAMD31D, TMD31D
Alternator 28V 60A, Components: 872021	127	
Alternator 28V 60A, Components: 873771	127B	
Alternator 14V 130A, Components	594	AD31D, AD31XD, TAMD31D, TMD31D
Alternator 28V 100A, Components	596	AD31D, AD31XD, TAMD31D, TMD31D
Alternator 28V 60A, Components: 872927	4942	AD31D, AD31XD, TAMD31D, TMD31D
Charging Distributor	258	AD31D, AD31XD, TAMD31D, TMD31D
Charging Distributor: 858841	365	AD31D, AD31XD, TAMD31D, TMD31D
Charging Distributor: 859499	365B	AD31D, AD31XD, TAMD31D, TMD31D
Charging Distributor: 873120	365C	AD31D, AD31XD, TAMD31D, TMD31D
Charging Distributor	368	AD31D, AD31XD, TAMD31D, TMD31D
Starter Motor	967	AD31D, AD31XD
Starter Motor	966	TAMD31D, TMD31D
Starter Motor, Components: 838987	968	AD31D, AD31XD, TAMD31D, TMD31D
Starter Motor, Components: 859252	583	AD31D, AD31XD, TAMD31D, TMD31D
Starter Motor, Components: 3581774	4930	AD31D, AD31XD, TAMD31D, TMD31D
Electrical System	959	AD31D, AD31XD, TAMD31D, TMD31D
Instrument Panel 24V	969	AD31D, AD31XD, TAMD31D, TMD31D
Instrument Panel 12V	584	AD31D, AD31XD, TAMD31D, TMD31D
Instrument Panel for Dual Station	662	AD31D, AD31XD, TAMD31D, TMD31D
Instrument Panel 12V	792	AD31D, AD31XD, TAMD31D, TMD31D
Instruments for Separate Mounting	799	AD31D, AD31XD, TAMD31D, TMD31D
Tank Meter Kit for Fuel	274	AD31D, AD31XD, TAMD31D, TMD31D
Speedometer Kit, High Speed	663	AD31D, AD31XD, TAMD31D, TMD31D
Electronic Speed and Distance Log Kit	664	AD31D, AD31XD, TAMD31D, TMD31D
Control Unit for Digital/Analog Trim Instrument	665	AD31D, AD31XD, TAMD31D, TMD31D
Rudder Indicator Kit, 290 Drive	667	AD31D, AD31XD, TAMD31D, TMD31D
Air Pressure Gauge	668	AD31D, AD31XD, TAMD31D, TMD31D
Instr. Panel for Twin Engine Install. Mirror-Invert	366	AD31D, AD31XD, TAMD31D, TMD31D
Rudder Indicator Kit for Reverse Gear	252	AD31D, AD31XD, TAMD31D, TMD31D
Clock Kit	253	AD31D, AD31XD, TAMD31D, TMD31D
Extra Instrument Panel, Hour Meter and Volt Meter	278	AD31D, AD31XD, TAMD31D, TMD31D
Tank Meter Kit for Fuel	9537	AD31D, AD31XD, TAMD31D, TMD31D
Tank Meter Kit for Fresh Water	35681	AD31D, AD31XD, TAMD31D, TMD31D
Oil Level Guard, 12V	1388	AD31D, AD31XD, TAMD31D, TMD31D
Main Battery Switch	260	AD31D, AD31XD, TAMD31D, TMD31D
Emergency Stop Contact	367	AD31D, AD31XD, TAMD31D, TMD31D
Electrical Materials	1963	AD31D, AD31XD, TAMD31D, TMD31D
Electrical Materials	1964	AD31D, AD31XD, TAMD31D, TMD31D
Electrical Materials	1965	AD31D, AD31XD, TAMD31D, TMD31D