



19355

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3832313	1	Hollow screw	
2	3831595	2	Sealing washer	
3	3835128	1	Gasket	
4	3818203	1	Gasket	(3835122)
5	3835123	1	Gasket	
6	3831576	2	Screw	
7	3832233	5	Spring washer	
8	3831575	2	Screw	
9	3835159	1	Oil pipe, oil cooler	
10	3832042	1	Screw	
11	3831898	1	Stay	
12	3832092	1	Screw	
13	3832277	1	Spring washer	
14	3831842	1	Oil pipe, fuel inj. pump	
15	3832310	1	Hollow screw	
16	3831588	2	Sealing washer	
17	3832311	1	Hollow screw	
18	3831591	2	Sealing washer	
19	3834124	1	Oil pipe	
20	3834007	1	Drain pipe	
21	3832058	2	Screw	
22	3832245	2	Spring washer	
23	3835725	2	Screw	
24	3832245	2	Spring washer	
25	3832218	2	Washer	
26	3807056	1	Oil pipe	(3834125)
27	3831569	3	O-ring	
28	3831834	1	Flange	
29	3831833	2	Plate	
30	3831639	2	Gasket	Replaced with 3838300 for contact to water and 3837677 for contact with lubricant.
31	3832089	2	Screw	
32	3832245	3	Spring washer	
33	3831605	2	Screw	
34	3831840	1	Overflow valve	
35	3834208	1	· Plate	
36	3834608	1	· Valve sleeve	
37	3834841	1	· Valve	
38	3834651	1	· Valve spring	
39	3834734	1	· Sleeve	
40	3831569	1	O-ring	
41		1	Adapteroil-filter housing	