


D3-110I-A, D3-110I-B, D3-110I-C, D3-130A-A, D3-130I-A, D3-130A-B, D3-130I-B, D3-130A-C, D3-130I-C, D3-160A-A, D3-160I-A, D3-160A-B, D3-160I-B, D3-160A-C, D3-160I-C, D3-190A-B, D3-190I-B, D3-190A-C, D3-190I-C



22726

D3-110I-A, D3-110I-B, D3-110I-C, D3-130A-A, D3-130I-A, D3-130A-B, D3-130I-B, D3-130A-C, D3-130I-C, D3-160A-A, D3-160I-A, D3-160A-B, D3-160I-B, D3-160A-C, D3-160I-C, D3-190A-B, D3-190I-B, D3-190A-C, D3-190I-C

REF	PART NO.	QTY	DESCRIPTION
1	3884631	1	Cover, complete
2	3808288	1	• Cover
3	3812607	1	• Cup
4	3819953	1	• End cover
5	969456	4	• 6 point socket screw
6	888512	4	• Bracket
7	8642162	4	• Rubber cushion
8	969476	4	• 6 point socket screw
9	888382	1	Decal
10	888383	1	Decal
11	3584298	1	Decal
12	3812572	1	Decal