


D34A-MT, D34A-MS



21160

D34A-MT, D34A-MS

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	3832311	1	Hollow screw		
2	3831591	2	Sealing washer		
3	3586424	1	Bracket		(3833001)
4	3836448	2	Screw		
5	3832233	2	Spring washer		
6	3832063	2	Screw		
7	3832245	2	Spring washer		
8	3832199	2	Lock nut		
9	3837004	1	Connector		
10	3837012	1	Fuel pipe		
11	3817747	1	Fuel pipe, fuel feed pump, S.B		(3837013)
12	3834034	1	Fuel pipe		P
13	3837014	1	Fuel pipe, fuel feed pump, P		
14	3832311	4	Hollow screw		
15	3831591	8	Sealing washer		
16	3831700	4	Clamp		
17	3831701	4	Seat		
18	3832047	2	Screw		
19	3832214	2	Washer		
20	3832233	2	Spring washer		
21	3831758	2	Lock nut		
22	3837015	4	Stay		
23	3835722	4	Screw		
24	3832225	4	Spring washer		
25	3836448	4	Screw		
26	3832233	4	Spring washer		
27	3834678	1	Stay		SB
28	3833060	1	Bracket		SB
29	3833048	1	Bracket		P
30	3831575	5	Screw		
31	3832233	5	Spring washer		
32	3832042	1	Screw		
33	3832233	1	Spring washer		
34	3832044	8	Screw		
35			Spring washer		
36	3834032	1	Fuel pipe		SB
37	3835047	1	Fuel filter		
				5242	