


D34A-MT, D34A-MS



D34A-MT, D34A-MS

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3832047	6	Screw	
2	3837000	1	Connector	
3	3837001	1	Connector	
4	3832196	6	Lock nut	
5	3832214	6	Washer	
6	3832233	6	Spring washer	
7	3832320	2	Connector	
8	3837002	1	Fuel pipe, injectionpump, S.B	SB
9	3831587	4	Sealing washer	
10	3837003	2	Hollow screw	
11	3837004	1	Connector	
12	3837005	2	Fuel pipe	
13	3837006	1	Connector	
14	3837007	1	Fuel pipe	P
15	3837009	1	Fuel pipe, injectionpump, P	P
16	3837010	1	Fuel pipe	SB
17	3831700	12	Clamp	
18	3831701	12	Seat	
19	3837011	1	Fuel pipe	
20	3832311	2	Hollow screw	
21	3831591	4	Sealing washer	
22	3835722	1	Screw	
23	3832225	1	Spring washer	