


D4-180I-F, D4-225A-F, D4-225I-F, D4-260A-F, D4-260D-F, D4-260I-F, D4-300A-F, D4-300D-F, D4-300I-F



26430

D4-180I-F, D4-225A-F, D4-225I-F, D4-260A-F, D4-260D-F, D4-260I-F, D4-300A-F, D4-300D-F, D4-300I-F

| REF | PART NO. | QTY | DESCRIPTION                 | NOTES  |
|-----|----------|-----|-----------------------------|--|
| 1   | 3594614  | 1   | Starter motor               | 12V, SOLAS   |
|     | 3801296  | 1   | Starter motor, exch, exch   | 12V, SOLAS   |
|     |          |     | • parts not sold separately |  |
|     | 21423489 | 1   | Starter motor, 24v 5        | 24V, SOLAS   |
|     |          |     | • parts not sold separately |  |
| 2   | 21389274 | 1   | Gasket                      |  |
| 3   | 21380910 | 1   | Gasket                      |  |
| 4   | 21308512 | 3   | Insulating bushing          |  |
| 5   | 845884   | 3   | Spacer sleeve               |  |
| 6   | 973246   | 3   | Hexagon screw               |  |
| 7   | 983714   | 1   | Hexagon nut                 |  |
| 8   | 983715   | 1   | Hexagon nut                 | negative pole  |
| 9   | 857180   | 1   | Spacer nut                  | positive pole  |
| 10  | 946670   | 1   | Flange screw                |  |
| 11  | 855798   | 1   | Protecting sleeve           |  |
| 12  | 3818845  | 1   | Starter relay               | 12V  |
|     | 3818856  | 1   | Starter relay               | 24V  |
| 13  | 948702   | 1   | Cable tie                   |  |
| 14  | 996153   | 1   | Chassis ground cable        | Do not use with transient protector                      |
| 15  | 21923306 | 1   | Wiring harness kit          | Transient protector, alternative to chassis ground cable |