


D49A-MT AUX, D49A-MS AUX



D49A-MT AUX, D49A-MS AUX

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	3839377	1	Injection pump		S.B 28"
2	3833153	1	· Housing		S.B
3	3833099	1	· Camshaft		
4	3834326	1	· Rack		
5	3838331	6	· Delivery valve		
6	3834762	6	· Tappet		
7	3833627	6	· Valve retainer		
8	3839518	6	· Tappet		
9	3835215	6	· Valve spring		
10	3838330	6	· Adjusting sleeve		
11	3835024	1	· Cover		
12	3835029	1	· Cover		
13	3832168	1	· Bearing		
14	3833847	18	· O-ring		Included in kit 3836466
15	3833095	2	· Bushing		
16	3832267	6	· Screw		
17	3832268	6	· Screw		
18	3834867	12	· Washer		
19	3833960	7	· Pin		
20	3833114	7	· Cap		
21		1	· Wire		
22	3832024	1	· Lead sealing tab		
23	3837381	1	· Valve		
24	3834292	1	· Setting indicator		
25	3832178	1	· Bellows		Included in repair kit No 3834338
26	3832272	12	· Screw		
27	3807054	2	· Screw		
28	3834433	1	· Set screw		
29	3834596	4	· Shim		
30	3834597	1	· Shim		
31	3834598	1	· Shim		
32	3834599	2	· Shim		
33	3834591	1	· Shim		
34	3834592	12	· Shim		
35	3834593	1	· Shim		
36	3834594	1	· Shim		
37	3834595	1	· Shim		
38	3832303	1	· Hollow screw		S.B
	3832305	1	· Hollow screw		P
39	3833818	2	· Flange nut		
40	3838901	2	· Washer		
41	3832308	2	· Hollow screw		
42	3832339	6	· Screw		
43	3832323	2	· Screw		
44	3837382	1	· Flywheel		
45	3837813	1	· Clutch		Repl. by clutch 3837813 and washer 3837814
46	3837383	1	· Clutch		
47	3834236	4	· Plate		
48	3834237	12	· Plate		
49	3833093	4	· Bushing		
50	3833097	4	· Bushing		
51	3834873	8	· Washer		
52		1	· Plate		
53	3832131	2	· Rivet		
54	3831586	3	· Sealing washer		Included in kit 3836466
55	3831587	12	· Sealing washer		Included in kit 3836466
56	3831588	1	· Sealing washer		Included in kit 3836466
57	3831591	6	· Sealing washer		Included in kit 3836466
58	3831526	2	· Screw		
59	3832223	2	· Spring washer		
60	3831555	1	· Screw		

D49A-MT AUX, D49A-MS AUX

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
61	3832225	4	• Spring washer		
62	3832038	4	• Screw		
63	3832225	4	• Spring washer		
64	3831534	3	• Screw		
65	3832223	3	• Spring washer		
66	3831790	3	• Washer		
67	3831777	1	• Lock nut		
68	3832277	1	• Spring washer		
69	3834855	1	• Washer		
70	3832285	1	• Woodruff key		
71	3834457	1	• Ring		Included in kit 3836466
72	3831873	2	• O-ring		
73	3831992	1	• O-ring		
74	3832003	2	• O-ring		
75	3831566	6	• O-ring		Included in kit 3836466
76	3832027	1	• Hollow screw		
77	3832328	1	• Plug		
78	3831623	2	• Bearing		
79	3836466	1	• Repair kit		
80	888755	6	• Pump element		(3834941)
81		6	• • Detent pinkit		
82		6	• • Pin		
83	3833985	6	• • Pinion		
84	3834490	6	• • Seat		
85	3834479	6	• • Seat		
86	3834661	6	• • Spring		
87	3833625	6	• • Retainer		
88	3834322	1	• Fuel pump		
				4986	