



5170

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	844459	1	Injector	
2		1	• NOZZLE HOLDER	
3	74033	1	• Hollow screw	
4	947620	2	• Gasket	(233321)
5	844294	1	• Gasket	
6	844295	1	• O-ring	
7	244443	1	• Fitting	
8	244444	1	• Spring	REPLACED BY 1EA 244820, 1EA 244821.
	244820	1	Compression spring	
9	244445	1	• Push rod	REPLACED BY 1EA 244820, 1EA 244821.
	244821	1	Pressure bolt	
10	844339	2	• Locating pin	
11	244447	2	• Pin	
12	1698513	1	• Washer	(244537)
13	244797	1	• Adjusting washer, SHIM	TH = 1,000 MM (844299)
	846960	1	• Adjusting washer	TH = 1,020 MM
	244798	1	• Adjusting washer	TH = 1,040 MM (846945)
	244788	1	• Adjusting washer	TH = 1,080 MM (846961)
	860174	1	• Adjusting washer	TH = 1,100 MM (844303)
	244804	1	• Adjusting washer, SHIM	TH = 1,120 MM (6212418)
	863780	1	• Adjusting washer	TH = 1,140 MM (846947)
	846963	1	• Adjusting washer, SHIM	TH = 1,175 MM (844343)
	244799	1	• Adjusting washer, SHIM	TH = 1,200 MM (844304)
	6212417	1	• Adjusting washer	TH = 1,220 MM
	244805	1	• Adjusting washer, SHIM	TH = 1,240 MM (846948)
	244807	1	• Adjusting washer, SHIM	TH = 1,280 MM (846964)
	859356	1	• Adjusting washer	TH = 1,300 MM (844308)
	244789	1	• Adjusting washer, SHIM	TH = 1,320 MM (846965)
	858908	1	• Adjusting washer, SHIM	TH = 1,340 MM (846950)
	846966	1	• Adjusting washer, SHIM	TH = 1,375 MM (844311)
	244800	1	• Adjusting washer, SHIM	TH = 1,400 MM (844312)
	6212393	1	• Adjusting washer	TH = 1,420 MM
	244790	1	• Adjusting washer	TH = 1,440 MM (856952)
	244802	1	• Adjusting washer, SHIM	TH = 1,475 MM (844315)
	859358	1	• Adjusting washer	TH = 1,500 MM (844316)
	244791	1	• Adjusting washer, SHIM	TH = 1,525 MM (844317)
	846954	1	• Adjusting washer	TH = 1,540 MM
	846969	1	• Adjusting washer	TH = 1,580 MM
	244793	1	• Adjusting washer	TH = 1,600 MM (844320)
	846970	1	• Adjusting washer	TH = 1,620 MM
	244806	1	• Adjusting washer, SHIM	TH = 1,640 MM (846956)
	244803	1	• Adjusting washer, SHIM	TH = 1,675 MM

REF	PART NO.	QTY	DESCRIPTION	NOTES
13				(844323)
	858905	1	· Adjusting washer	TH = 1,700 MM
				(844324)
	244794	1	· Adjusting washer, SHIM	TH = 1,725 MM
				(844325)
	846957	1	· Adjusting washer	TH = 1,740 MM
	846975	1	· Adjusting washer	TH = 1,780 MM
	844328	1	· Adjusting washer	TH = 1,800 MM
	6212420	1	· Adjusting washer, SHIM	TH = 1,825 MM
				(844329)
	846958	1	· Adjusting washer	TH = 1,840 MM
	244813	1	· Adjusting washer, SHIM	TH = 1,880 MM
				(846977)
	844332	1	· Adjusting washer	TH = 1,900 MM
	244795	1	· Adjusting washer, SHIM	TH = 1,920 MM
				(846978)
	846959	1	· Adjusting washer	TH = 1,940 MM
	846980	1	· Adjusting washer	TH = 1,980 MM
14	844460	1	· Nozzle	
15	244448	1	· Cap nut	