



10616

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	860953	2	Engine bracket	
2	965192	7	Flange screw	L=40mm
	965193	1	Flange screw	L=50mm
3	940280	8	Spring washer	
4	860952	1	Engine bracket	P
	860954	1	Engine bracket	S.B
5	940280	4	Spring washer	
6	966343	3	Flange screw	L=35mm
	965226	3	Flange screw	L=45mm
7	861302	4	Rubber cushion	
8	955900	4	• Washer	
9	860950	4	• Adjusting screw	
10	955806	8	• Hexagon nut	
11	955901	4	Washer	D=34mm
	978991	4	Washer	D=40mm
11A	941913	4	Spring washer	