



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	850057	1	Upper gear unit		
2	850058	1	· Gear housing		
3	961638	1	· Pin		
4	832189	1	· Washer		
5	850060	1	· Cover		
6	804342	1	· · Screw		
7	804344	1	· · Gasket	IK	
8	832140	1	· · Washer		
9	832127	1	· Gear set		
10	181290	2	· Ball bearing		
11	832920	1	· Bearing box		
12	832128	X	· Intermediate ring		TH = 11,850 MM
	832129	X	· Intermediate ring		TH = 11,875 MM
	832130	X	· Intermediate ring		TH = 11,900 MM
	832131	X	· Intermediate ring		TH = 11,925 MM
	832132	X	· Intermediate ring		TH = 11,950 MM
	832133	X	· Intermediate ring		TH = 11,975 MM
	832134	X	· Intermediate ring		TH = 12,000 MM
	851731	X	· Intermediate ring		TH = 12,025 MM
	851732	X	· Intermediate ring		TH = 12,050 MM
	851733	X	· Intermediate ring		TH = 12,075 MM
	851734	X	· Intermediate ring		TH = 12,100 MM
13	907025	1	· Lock washer	IK	
14	832923	1	· Nut		
15	832952	1	· Gasket	IK	
16	832921	1	· Bearing cover		
17	958856	1	· Sealing ring	IK	
18	955995	1	· O-ring	IK	
19	850205	1	· Axle shaft		
20	946292	1	· Screw		
21	850203	1	· Washer		
22	925094	1	· O-ring	IK	
23	804301	X	· Adjusting washer		TH = 0,05 MM
	804221	X	· Adjusting washer		TH = 0,10 MM
	804394	X	· Adjusting washer		TH = 0,20 MM
24	959224	5	· Screw		L = 35 MM
	959222	1	· Screw		L = 25 MM
25	941907	6	· Spring washer		
26	813949	1	· Bearing sleeve		
27	951953	1	· Pin		
28	850336	1	· Anchorage		
29	959194	4	· Screw		
30	181287	2	· Ball bearing		
31	850290	1	· Shaft		
32	850303	1	· Sleeve		
33	914456	1	· Lock ring		
34	850987	1	· Washer		
35	813970	1	· Spring		
36	181268	4	· Needle bearing		
37	813939	3	· Spacer ring		
38	850761	2	· Pin		
39	87655	X	· Adjusting washer		TH = 0,10 MM
	191840	X	· Adjusting washer		TH = 0,15 MM
40	813941	X	· Spacer ring		TH = 5,0 MM
	813971	X	· Spacer ring		TH = 5,1 MM
	813972	X	· Spacer ring		TH = 5,2 MM
	813973	X	· Spacer ring		TH = 5,3 MM
	813974	X	· Spacer ring		TH = 5,4 MM
41	814030	2	· Lock ring		
42	959224	4	· Screw		
43	948486	X	· Washer		TH = 0,05 MM
	948487	X	· Washer		TH = 0,10 MM
	948488	X	· Washer		TH = 0,20 MM
44	925257	2	· O-ring		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
45	834021	1	· Lever		
46	955270	2	· Screw		
47	955948	2	· Lock washer		
48	955781	2	· Nut		
49	804312	1	· Cube		
50	955892	1	· Washer		
51	907834	1	· Cotter pin		
52	839505	1	· Bearing housing		
53	897816	1	· Eccentric piston · Bulletin P-44-1-7	P-44-1-7-EN	Shift mechanism, eccentric piston
54	897711	1	· Screw		
55	814184	1	· Spring		
56	897871	X	· Adjusting washer		TH = 0,20 MM
57	839646	1	· Dog		
58	942871	1	· Pin		
59	951924	1	· Tensioning din		
60	958838	1	· Sealing ring	IK	(941866)
61	925093	1	· O-ring	IK	
62	850350	1	· Cable attachment		
63	819067	1	· Brace		
64	819068	1	· Washer		
65	955246	2	· Screw		
66	946577	2	· Lock nut		
66A	940090	2	· Washer		
67	941906	4	· Spring washer		
68	955272	4	· Screw		
69	850207	1	· Dipstick		
70	850209	1	· Tube		
71	925054	1	· O-ring	IK	
72	851314	1	· Bracket		(850332)
73	960148	4	· Washer		
74	955318	4	· Screw		
75	952076	1	· Plug		
76	852230	1	Tap		SEE GROUP 4A
77	801197	1	· Hose attachment		
78	850759	1	Hose clamp		