



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	(833622)	1	Instrument panel		Obsolete part
2		1	• panel		Replaced by 831993 + 2ea 875819 + 2ea 837726.
3	836467	1	• Tachometer		
4	(841233)	1	• Thermometer		(831475), Obsolete part
5	824963	1	• Starter switch		
6	(831606)	2	• • Key		State key code when ordering, Obsolete part
			Bulletin P-36-4-1	P-36-4-1-EN	Deleted Part No's for Keys
7	(827769)	1	• Collar		Obsolete part
8	(831499)	2	• Switch		Obsolete part
9	843002	2	• • Nut		
10	(827765)	2	• Knob		Knob with thread., Early type, Obsolete part
11	827766	2	• Lens		
12	819350	2	• Sleeve		
13	808175	3	• Lamp socket		
14	(808174)	1	• Lamp socket		Obsolete part
15	19923	4	• Bulb		
16	(833614)	1	• Cable trunk		Obsolete part
17	(831536)	1	• Nut		Obsolete part
18	944540	4	• Screw		
19		X	• cables and terminals	13791	
20	948210	X	• Cable tie		(827353)
21	(951666)	2	• E-circlip		Obsolete part
22	(833985)	1	• Capacitor		Obsolete part