



MD2B

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	(833167)	1	Crankcase		Obsolete part
2	955075	3	• Plug		
3	(955073)	1	• Plug		Obsolete part
4	803330	1	• Camshaft bushing		
5	(833158)	1	• Bearing		Obsolete part
6	405177	1	• Bearing		
7	950586	2	Pin	13740	
8	(807045)	3	Plug		Obsolete part
9	(418440)	1	Nipple	13745	Obsolete part
10	947789	1	O-ring		
11	(897271)	1	Set screw		Obsolete part
12	833792	2	Gasket		
13	(803258)	2	Inspection lid		Obsolete part
14	941907	12	Spring washer		
15	955294	12	Hexagon screw		MO-23007
	959219	12	Hex. socket screw		MO 23008-
16	(833390)	1	Bearing cover		Obsolete part
17	(955074)	1	• Plug		Obsolete part
18	946742	1	O-ring		
19	946743	1	O-ring		
20	944722	1	Stud		Engine with dynastart.
	(946928)	1	Stud		Engine with starter motor., Obsolete part
21	946075	9	Washer		
22	963107	1	Lock nut		
23	955322	4	Hexagon screw		L=50mm
	955318	2	Hexagon screw		Engine with dynastart., L=30mm
	955320	2	Hexagon screw		Engine with dynastart., L=40mm
	955318	1	Hexagon screw		Engine with starter motor., L=30mm
	955320	1	Hexagon screw		Engine with starter motor., L=40mm
	955326	2	Hexagon screw		Engine with starter motor., L=70mm
24	803359	1	Gasket		
25	(803236)	1	Cover		Obsolete part
26	941907	4	Spring washer		
27	955296	4	Hexagon screw		
28	803356	1	Sealing ring	13758	
29	807044	1	Plug		MO-13532, 13619-13799
	(833521)	1	Plug		MO 13533-13618, 13800-, Obsolete part
30	957181	1	Gasket		MO 13533-13618, 13800-
31	(897251)	8	Stud	13743	Obsolete part
32	(875513)	2	Cylinder block		Obsolete part
33	833497	2	• Spacer		TH=0.2mm
	833498	2	• Spacer		TH=0.3mm
34		2	• piston kit		
			• •	13758	
35	(807125)	2	• Plug		Obsolete part
36	18811	2	• Gasket		
37	(807054)	1	Set screw		See group 2C, Obsolete part
38	(807027)	2	Nipple	13745	Obsolete part
39	(807081)	1	Elbow nipple		Obsolete part
40	807036	2	Shut-off cock		