



3947

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	839516	1	Mounting kit	For sail boat., Early type
2	839518	1	• Cover	
3	839521	1	• Hand lever	For sail boat.
4	946786	1	• Lock screw	M5, Obsolete part
	839693	1	• Lock screw	M8
5	955142	4	• Cross recessed screw	
6	839469	1	Control	Early type
7	839641	1	Neutral position con	
8	839619	1	• Cable kit	Obsolete part
9	850200	1	• • Toggle switch	
10		X	• • cable and terminals	See group 3
11	1501832	1	• Relay	
12	946177	2	• Cross recessed screw	
13	947536	2	• Hexagon nut	
14		1	• Coupling piece	