



REF	PART NO.	QTY	DESCRIPTION	NOTES
	833031	1		
1		1	· HOUSING	
2		4	· POLE SHOE	
3	956130	4	· Screw	
4	243424	1	· Field winding	
5	243425	1	· Field winding	
6	243426	1	· Local part	
7	243427	1	· Bearing shield	
8	76603	1	· · Bushing	
9	243428	1	· Bearing	
10	72483	1	· · Bushing	
11	243429	1	· Washer	
12	243430	1	· Arm	
13	72481	1	· Arm	
14	120649	X	· Adjusting washer	TH = 0,1 MM
	238834	X	· Adjusting washer	TH = 0,3 MM
15	941906	1	· Spring washer	
16	955781	1	· Nut	
17	243431	1	· Start gear	
18	243436	2	· · Bushing	
19	243432	1	· Rotor	
20	241321	1		
21	240332	1	· Ring	
22	240333	1	· Lock ring	
23	240610	X	· Adjusting washer	TH = 0,2 MM
	120657	X	· Adjusting washer	TH = 0,3 MM
	243433	X	· Washer	TH = 1,0 MM
24	243434	1	· Bearing	
25	243437	1	· · Bushing	
26	233679	1	· · Carbon brush set	
27	76601	4	· · Spring	
28	956059	2	· · Screw	
29	955917	2	· · Spring washer	
30	120648	1	· · Washer	
31	76604	2	· · Brake shoe	
32	239547	2	· · Bushing	
33	76605	2	· · Spring	
34	956059	2	· Screw	
35	233872	1	· Link	
36	239552	2		
37	86287	2	· Washer	
38	941906	2	· Spring washer	
39	241326	1	· Cover	
40	241327	1	· Gasket	
41	956073	2	· Screw	
42	243435	1	· Relay	
43	956094	2	· Screw	
44	941906	2	· Spring washer	
45	941907	2	· Spring washer	
46	955782	2	· Nut	