



REF	PART NO.	QTY	DESCRIPTION	NOTES
	833669	1	Starter motor	
	3803073	1	Starter motor, exch	Exchange unit
1		1	· HOUSING	
2		4	· POLE SHOE	
3	956130	4	· Screw	
4	833724	1	· Field winding	
5	833725	1	· Bearing shield	
6	238813	1	· · Bushing	
7	833726	1	· Bearing	
8	833739	1	· · Bushing	
9	833727	1	· Engagement lever	
10	241674	1	· Screw	
11	941906	1	· Spring washer	
12	955781	1	· Nut	(244116)
13	833730	1	· Start gear	
14	240620	2	· · Bushing	
15	238819	1	· Stop ring	
16	833729	1	· Rotor	
17		1	· PLATE	
18	840525	1	· Carbon brush set	(833733)
19	834519	4	· Spring	(241887)
20	240601	1	· Bearing	
21	240602	1	· · Bushing	
22	833734	2	· Screw	
23	86287	2	· Washer	
24	240606	1	· Cover	
25	956059	2	· Screw	(241292)
26	941904	2	· Spring washer	
27	833735	1	· Actuator solenoid	
28	240626	X	· · Adjusting washer	TH = 0,5 MM
	240627	X	· · Adjusting washer	TH = 1,0 MM
29	243248	1	· · Cover	
30	833737	2		
31	941905	2	· · Spring washer	
32	955224	1	· · Screw	
33	240499	1	· · Washer	
34	955782	1	· Nut	
35	941907	1	· Spring washer	
36	833736	2	· Screw	
37	241300	1	· Repair kit	
38		1	· INSULATOR	