

PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
876657	1	Main bearing kit	146	STD D
876658	1	Main bearing kit		U.S=0,25mm
876659	1	Main bearing kit		U.S=0,50mm
861957	2	Piston kit	146	STD D
861958	2	Piston kit		O.S=0,25mm
861959	2	Piston kit		O.D=0,50mm
861954	2	Piston ring kit	146	STD D
861955	2	Piston ring kit		O.S=0,25mm
861956	2	Piston ring kit		O.D=0,50mm
876669	1	Big end bearing kit	146	STD D
876670	1	Big end bearing kit		U.S=0,25mm
876671	1	Big end bearing kit		U.S=0,50mm
875807	1	Impeller kit		(876689)
833550	1	• Impeller		
803730	1	• Screw		
833417	1	• Gasket		
3580900	1	Repair kit, sea water pump		
	1	• Shaft		
181743	2	• Ball bearing		
951086	1	• Lock ring		
951075	2	• Snap ring		
3580903	2	• Sealing ring		

PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
925054	1	· O-ring		
3580906	1	· Cam		
860201	1	· Screw		
817825	6	· Screw		
3580907	1	· Wear washer		
3580908	1	· Cover		
3580918	1	· O-ring		
876688	1	Repair kit, fuel feed pump	171	
876653	1	Gasket kit		
861536	1	· Gasket		
861822	1	· Gasket		
861823	1	· Sealing ring		
861830	1	· O-ring		
861835	1	· Gasket		
861836	1	· Gasket		
861838	1	· Gasket		
861841	4	· Gasket		
861851	4	· O-ring		
861860	4	· Valve stem seal		
861865	1	· Gasket		
861868	6	· Gasket		
861887	1	· Gasket		
861888	1	· Gasket		
861897	1	· O-ring		
861907	1	· Gasket		
861909	1	· Gasket		
861917	1	· Gasket		
861997	1	· O-ring		
3580001	1	· Gasket		
3580003	1	· Gasket		
3580025	1	· Gasket		
3580026	1	· Sealing ring		
3580060	1	· Gasket		
3580063	1	· O-ring		
3580069	1	· Spacer		TH = 0,2mm
3580070	1	· Spacer		TH = 0,3mm
3580071	1	· Spacer		TH = 0,4mm
3580072	1	· Spacer		TH = 0,5mm
3580075	2	· Gasket		
3580077	2	· Gasket		
3580092	1	· Gasket		
3580097	5	· Gasket		
3580111	1	· Gasket		
3580153	2	· Sealing washer		
3580159	2	· Washer		
3580203	4	· Sealing washer		

PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES

